



**Australian Hammer Supplies Hire**  
Unit 3/32 Williamson Road  
Ingleburn  
NSW 2565

## D1000 APG 10T DUMP TRUCK

### Major Service

0 12 71 22

|                   |                                                                                     |                  |                                    |
|-------------------|-------------------------------------------------------------------------------------|------------------|------------------------------------|
| Inspection Number | RP060847                                                                            | Customer No      | 200000                             |
| Serial Number     | 63180179                                                                            | Customer Name    | AUSTRALIAN HAMMER<br>SUPPLIES HIRE |
| Make              | AUSA                                                                                | Customer Email   |                                    |
| Model             | D1000APG                                                                            | Works Order      | RP060847                           |
| Equipment Family  | Dump Truck Swivel 10 Tonne                                                          | Completed On     | 25/08/2026 7:24:17 AM              |
| Asset ID          | AHSH71                                                                              | Inspector        | Collin Graham                      |
| Location          | AUSTRALIAN HAMMER SUPPLIES HIRE<br>Unit 3/32 WILLIAMSON RD<br><br>INGLEBURN<br>2565 | PDF Generated On | 25/08/2026                         |
|                   |                                                                                     | Machine Hours    | 2682                               |
|                   |                                                                                     | Next Meter       | 2750                               |
| Customer          |  |                  |                                    |

### General Info & Comments

- **General Info/Comments** *carry out service as required*

### TASK SAFETY INSTRUCTIONS

- |                                                                                           |      |
|-------------------------------------------------------------------------------------------|------|
| ● <b>1.1 Wear Correct PPE at all times</b>                                                | PASS |
| ● <b>1.2 All isolation and safe work procedures must be followed</b>                      | PASS |
| ● <b>1.3 Identify task hazards and controls utilising hierarchy or controls model</b>     | PASS |
| ● <b>1.4 Ensure a competent operator and spotter is utilised to move mobile equipment</b> | PASS |
| ● <b>1.5 Ensure all mobile equipment is fundamentally stable</b>                          | PASS |
| ● <b>1.6 Ensure three points of contact is maintained during access and egress</b>        | PASS |
| ● <b>1.7 Ensure acceptable housekeeping standards are maintained at all times</b>         | PASS |

## MACHINE GENERAL RUNNINGCHECKS

|   |                                                                                   |      |
|---|-----------------------------------------------------------------------------------|------|
| ● | 2.1 Check all work lights, beacon & reverse alarmfor operation                    | PASS |
| ● | 2.2 Test all dash warning lights, gauges and audible alarms for correct operation | PASS |
| ● | 2.3 Check idle timer for correct shut down operation                              | PASS |
| ● | 2.4 Check operation of all three emergency stop buttons                           | PASS |
| ● | 2.5 Check operation of horn                                                       | PASS |
| ● | 2.6 Check operation of reverse camera                                             | PASS |
| ● | 2.7 Check alternator charge voltage                                               | PASS |
| ● | 2.8 Check operation of auto grease systemby manually activating timer             | N/A  |
| ● | 2.9 Check fire systemcontrol panel for 'Normal'                                   | N/A  |

## PM FIRE SUPPRESSION SYSTEM

|   |                                                                                              |                                          |
|---|----------------------------------------------------------------------------------------------|------------------------------------------|
| ● | 5.1 Ensure fire suppression bottle and components are securely mounted and in good condition | N/A                                      |
| ● | 5.2 Ensure fire suppression is correctly charged                                             | N/A                                      |
| ● | 5.3 Inspect last charge date                                                                 | DATE:2026-08-25<br>T00:00:00.000000<br>0 |
| ● | 5.4 Check all fire extinguishers are securely mounted and in good condition                  | PASS                                     |
| ● | 5.5 Check all fire extinguishers are correctly charged                                       | PASS                                     |
| ● | 5.6 Inspect last charge date                                                                 | DATE:2026-07-25<br>T00:00:00.000000<br>0 |

## PM ENGINE

|   |                                                                             |      |
|---|-----------------------------------------------------------------------------|------|
| ● | 6.1 Performengine valve set                                                 | N/A  |
| ● | 6.2 Inspect air intake systemhoses, pipes, clamps for signs of dirt ingress | PASS |
| ● | 6.3 Inspect engine for oil or fuel leaks                                    | PASS |

|                                                                                |         |
|--------------------------------------------------------------------------------|---------|
| ● 6.4 Inspect engine components for missing clamps                             | PASS    |
| ● 6.5 Inspect exhaust system for signs of leaks, loose bolts or missing clamps | PASS    |
| ● 6.6 Inspect turbo for security and signs of leaks                            | PASS    |
| ● 6.7 Inspect condition of exhaust lagging                                     | PASS    |
| ● 6.8 Inspect engine mounts for condition and loose hardware                   | PASS    |
| ● 6.9 Inspect alternator mount condition and adjustment                        | PASS    |
| ● 6.10 Inspect wiring condition and security                                   | MONITOR |
| ● 6.11 Inspect engine belts                                                    | PASS    |

## PM ENGINE COOLING SYSTEM

|                                                |      |
|------------------------------------------------|------|
| ● 7.1 Check coolant level                      | PASS |
| ● 7.2 Check condition of radiator cap          | PASS |
| ● 7.3 Check condition of radiator core         | PASS |
| ● 7.4 Check cooling system for signs of leaks  | PASS |
| ● 7.5 Check hose and clamp condition           | PASS |
| ● 7.6 Inspect fan condition and operation      | PASS |
| ● 7.7 Inspect radiator and fan guard condition | PASS |

## PM SWING TRANSMISSION

|                                                     |     |
|-----------------------------------------------------|-----|
| ● 8.1 Inspect swing transmission for signs of leaks | N/A |
| ● 8.2 Inspect swing transmission oil level          | N/A |

## PM HYDRAULIC SYSTEM

|                                                           |      |
|-----------------------------------------------------------|------|
| ● 9.1 Check hydraulic oil level                           | PASS |
| ● 9.2 Inspect hydraulic cylinders for leaks and security  | PASS |
| ● 9.3 Inspect hydraulic hoses for leaks, damage, security | PASS |

|                                                         |      |
|---------------------------------------------------------|------|
| ● 9.4 Inspect hydraulic pump condition, leaks, security | PASS |
|---------------------------------------------------------|------|

|                                                                                                                         |      |
|-------------------------------------------------------------------------------------------------------------------------|------|
| ● 9.5 Check Pilot Accumulator operation as per OEM Maintenance Procedure - Test Boom Down Functionality with engine off | PASS |
|-------------------------------------------------------------------------------------------------------------------------|------|

## PM FINAL DRIVES

|                                                                       |      |
|-----------------------------------------------------------------------|------|
| ● 10.1 Inspect LHS final drive mount condition for leaks and security | PASS |
|-----------------------------------------------------------------------|------|

|                                                     |      |
|-----------------------------------------------------|------|
| ● 10.2 Inspect LHS oil level and mag plug condition | PASS |
|-----------------------------------------------------|------|

|                                                                       |      |
|-----------------------------------------------------------------------|------|
| ● 10.3 Inspect RHS final drive mount condition for leaks and security | PASS |
|-----------------------------------------------------------------------|------|

|                                                     |      |
|-----------------------------------------------------|------|
| ● 10.4 Inspect RHS oil level and mag plug condition | PASS |
|-----------------------------------------------------|------|

## PM UNDERCARRIAGE

|                                  |     |
|----------------------------------|-----|
| ● 11.1 Inspect LHS track tension | N/A |
|----------------------------------|-----|

|                                  |     |
|----------------------------------|-----|
| ● 11.2 Inspect RHS track tension | N/A |
|----------------------------------|-----|

|                                               |     |
|-----------------------------------------------|-----|
| ● 11.3 Inspect tracks for loose/missing bolts | N/A |
|-----------------------------------------------|-----|

|                                                            |     |
|------------------------------------------------------------|-----|
| ● 11.4 Inspect load and carrier rollers for signs of leaks | N/A |
|------------------------------------------------------------|-----|

|                                          |     |
|------------------------------------------|-----|
| ● 11.5 Inspect idlers for signs of leaks | N/A |
|------------------------------------------|-----|

|                                            |     |
|--------------------------------------------|-----|
| ● 11.6 Inspect sprocket segments condition | N/A |
|--------------------------------------------|-----|

|                                                                 |     |
|-----------------------------------------------------------------|-----|
| ● 11.7 Inspect track frame for cracks, lose or missing hardware | N/A |
|-----------------------------------------------------------------|-----|

## PM FRAME AND BODY

|                                             |      |
|---------------------------------------------|------|
| ● 12.1 Check panels for damage and security | PASS |
|---------------------------------------------|------|

|                                                 |      |
|-------------------------------------------------|------|
| ● 12.2 Check access steps and walkway condition | PASS |
|-------------------------------------------------|------|

|                                                                                                        |      |
|--------------------------------------------------------------------------------------------------------|------|
| ● 12.3 Inspect boom condition – cracks, missing clamps, damaged pipes, excessive movement, lubrication | PASS |
|--------------------------------------------------------------------------------------------------------|------|

|                                                                                                         |      |
|---------------------------------------------------------------------------------------------------------|------|
| ● 12.4 Inspect stick condition – cracks, missing clamps, damaged pipes, excessive movement, lubrication | PASS |
|---------------------------------------------------------------------------------------------------------|------|

|                                                    |      |
|----------------------------------------------------|------|
| ● 12.5 Inspect quick hitch condition and operation | PASS |
|----------------------------------------------------|------|

|                                                                |      |
|----------------------------------------------------------------|------|
| ● 12.6 Inspect bucket condition – cracks, wear, damage, mounts | PASS |
|----------------------------------------------------------------|------|

● 12.7 Inspect GET condition and hardware *PASS*

## PM ELECTRICAL SYSTEM

● 13.1 Check battery condition *PASS*

● 13.2 Check battery terminal condition *PASS*

● 13.3 Check battery security *PASS*

● 13.4 Check battery box drain is clear *PASS*

● 13.5 Check wiring condition and security *PASS*

## PM GREASE SYSTEM

● 14.1 Check all points for acceptable lubrication *PASS*

● 14.2 Inspect grease system operation *PASS*

● 14.3 Check grease line condition *PASS*

● 14.4 Refill grease tank *N/A*

● 14.5 Lubricate bucket linkage *PASS*

● 14.6 Lubricate blade linkage *N/A*

● 14.7 Lubricate boom & stick linkage *N/A*

● 14.8 Lubricate swing bearing *N/A*

## PM OPERATOR STATION

● 15.1 Check all doors for correct opening and closing adjustments and operation *PASS*

● 15.2 Inspect condition of door seals *PASS*

● 15.3 Check window glass and seal condition *PASS*

● 15.4 Check mirror condition and adjustments *PASS*

● 15.5 Fill window washer reservoir *N/A*

● 15.6 Inspect air con vents condition *N/A*

|   |                                                     |      |
|---|-----------------------------------------------------|------|
| ● | 15.7 Inspect seat belt and mounting hardware        | PASS |
| ● | 15.8 Inspect seat condition, operation and mounting | PASS |
| ● | 15.9 Replace cabin A/C filter                       | N/A  |

#### OIL SAMPLING

|   |             |      |
|---|-------------|------|
| ● | 16.1 Engine | PASS |
|---|-------------|------|

#### PM POST SERVICE INSPECTION CHECKS

|   |                                                                                                                  |      |
|---|------------------------------------------------------------------------------------------------------------------|------|
| ● | 17.1 All inspections have been completed and rectified as required                                               | PASS |
| ● | 17.2 All safety related defects have been repaired or reported                                                   | PASS |
| ● | 17.3 All defects have been noted and reported                                                                    | PASS |
| ● | 17.4 All fluids are at correct level and drain plugs tight                                                       | PASS |
| ● | 17.5 All oil samples have visually been inspected and any notable signs of contamination have been reported      | PASS |
| ● | 17.6 All replaced filters have been cut and inspected and photos added to CAT Inspect and reported to supervisor | PASS |
| ● | 17.7 Machine has been recommissioned and ready for operation                                                     | PASS |
| ● | 17.8 PM service notification marked off in Vision Link                                                           | N/A  |

#### DEFECTS IDENTIFIED

|   |                         |    |
|---|-------------------------|----|
| ● | 18.1 DEFECTS IDENTIFIED | na |
|---|-------------------------|----|

#### OIL USED

|   |                    |   |
|---|--------------------|---|
| ● | 19.1 Hydraulic oil | 0 |
| ● | 19.2 Engine oil    | 0 |
| ● | 19.3 Slew oil      | 0 |
| ● | 19.4 Gear oil      | 0 |
| ● | 19.5 Coolant       | 0 |