



Australian Hammer Supplies Hire
Unit 3/32 Williamson Road
Ingleburn
NSW 2565

D1000 APG 10T DUMP TRUCK

Minor Service


0 14 64 29

Inspection Number	RP061025	Customer No	200000
Serial Number	63180179	Customer Name	AUSTRALIAN HAMMER SUPPLIES HIRE
Make	AUSA	Customer Email	
Model	D1000APG	Works Order	RP061025
Equipment Family	Dump Truck Swivel 10 Tonne	Completed On	1/07/2026 1:41:34 PM
Asset ID	AHSH71	Inspector	Collin Graham
Location	AUSTRILAN HAMMER SUPPLIES HIRE Unit 3/32 WILLIAMSON RD INGLEBURN 2565	PDF Generated On	01/07/2026
		Machine Hours	2754
		Next Meter	3000
Customer			

General Info & Comments

General Info/Comments

2750hr



TASK SAFETY INSTRUCTIONS

1.1 Wear Correct PPE at all times	PASS
1.2 All isolation and safe work procedures must be followed	PASS
1.3 Identify task hazards and controls utilising hierarchy or controls model	PASS
1.4 Ensure a competent operator and spotter is utilised to move mobile equipment	PASS
1.5 Ensure all mobile equipment is fundamentally stable	PASS
1.6 Ensure three points of contact is maintained during access and egress	PASS
1.7 Ensure acceptable housekeeping standards are maintained at all times	PASS

MACHINE GENERAL RUNNINGCHECKS

●	2.1 Check all work lights, beacon & reverse alarm for operation	PASS
●	2.2 Test all dash warning lights, gauges and audible alarms for correct operation	PASS
●	2.3 Check idle timer for correct shut down operation	PASS
●	2.4 Check operation of all three emergency stop buttons	PASS
●	2.5 Check operation of horn	PASS
●	2.6 Check operation of reverse camera	PASS
●	2.7 Check alternator charge voltage	PASS
●	2.8 Check operation of auto grease system by manually activating timer	N/A
●	2.9 Check fire system control panel for 'Normal'	N/A

PM FIRE SUPPRESSION SYSTEM

●	5.1 Ensure fire suppression bottle and components are securely mounted and in good condition	N/A
●	5.2 Ensure fire suppression is correctly charged	N/A
●	5.3 Inspect last charge date	DATE: 2026-07-01 T00:00:00.000000 0
●	5.4 Check all fire extinguishers are securely mounted and in good condition	PASS
●	5.5 Check all fire extinguishers are correctly charged	PASS
●	5.6 Inspect last charge date	DATE: 2026-07-01 T00:00:00.000000 0

PM ENGINE

●	6.1 Perform engine valve set	N/A
●	6.2 Inspect air intake system hoses, pipes, clamps for signs of dirt ingress	PASS
●	6.3 Inspect engine for oil or fuel leaks	PASS
●	6.4 Inspect engine components for missing clamps	PASS

●	6.5 Inspect exhaust systemfor signs of leaks, loose bolts or missing clamps	PASS
●	6.6 Inspect turbo for security and signs of leaks	PASS
●	6.7 Inspect condition of exhaust lagging	PASS
●	6.8 Inspect engine mounts for condition and loose hardware	PASS
●	6.9 Inspect alternator mount condition and adjustment	PASS
●	6.10 Inspect wiring condition and security	PASS
●	6.11 Inspect engine belts	PASS
PM ENGINE COOLINGSYSTEM		
●	7.1 Check coolant level	PASS
●	7.2 Check condition of radiator cap	PASS
●	7.3 Check condition of radiator core	PASS
●	7.4 Check cooling systemfor signs of leaks	PASS
●	7.5 Check hose and clamp condition	PASS
●	7.6 Inspect fan condition and operation	PASS
●	7.7 Inspect radiator and fan guard condition	PASS
PM SWINGTRANSMISSION		
●	8.1 Inspect swing transmission for signs of leaks	N/A
●	8.2 Inspect swing transmission oil level	N/A
PM HYDRAULIC SYSTEM		
●	9.1 Check hydraulic oil level	PASS
●	9.2 Inspect hydraulic cylinders for leaks and security	PASS
●	9.3 Inspect hydraulic hoses for leaks, damage, security	PASS
●	9.4 Inspect hydraulic pump condition, leaks, security	PASS

- | | | |
|----------------------------------|---|------|
| ☒ | 9.5 Check Pilot Accumulator operation as per OEM Maintenance Procedure - Test Boom Down Functionality with engine off | PASS |
|----------------------------------|---|------|

PM FINAL DRIVES

- | | | |
|----------------------------------|---|------|
| ☒ | 10.1 Inspect LHS final drive mount condition for leaks and security | PASS |
| ☒ | 10.2 Inspect LHS oil level and mag plug condition | PASS |
| ☒ | 10.3 Inspect RHS final drive mount condition for leaks and security | PASS |
| ☒ | 10.4 Inspect RHS oil level and mag plug condition | PASS |

PM UNDERCARRIAGE

- | | | |
|----------------------------------|---|------|
| ☐ | 11.1 Inspect LHS track tension | N/A |
| ☐ | 11.2 Inspect RHS track tension | N/A |
| ☐ | 11.3 Inspect tracks for loose/missing bolts | N/A |
| ☐ | 11.4 Inspect load and carrier rollers for signs of leaks | N/A |
| ☐ | 11.5 Inspect idlers for signs of leaks | N/A |
| ☐ | 11.6 Inspect sprocket segments condition | N/A |
| ☒ | 11.7 Inspect track frame for cracks, lose or missing hardware | PASS |

PM FRAME AND BODY

- | | | |
|----------------------------------|---|------|
| ☒ | 12.1 Check panels for damage and security | PASS |
| ☒ | 12.2 Check access steps and walkway condition | PASS |
| ☐ | 12.3 Inspect boom condition – cracks, missing clamps, damaged pipes, excessive movement, lubrication | N/A |
| ☐ | 12.4 Inspect stick condition – cracks, missing clamps, damaged pipes, excessive movement, lubrication | N/A |
| ☐ | 12.5 Inspect quick hitch condition and operation | N/A |
| ☒ | 12.6 Inspect bucket condition – cracks, wear, damage, mounts | PASS |
| ☐ | 12.7 Inspect GET condition and hardware | N/A |

PM ELECTRICAL SYSTEM

☒	13.1 Check battery condition	PASS
☒	13.2 Check battery terminal condition	PASS
☒	13.3 Check battery security	PASS
☒	13.4 Check battery box drain is clear	PASS
☒	13.5 Check wiring condition and security	PASS

PM GREASE SYSTEM

☒	14.1 Check all points for acceptable lubrication	PASS
☐	14.2 Inspect grease system operation	N/A
☒	14.3 Check grease line condition	PASS
☐	14.4 Refill grease tank	N/A
☒	14.5 Lubricate bucket linkage	PASS
☐	14.6 Lubricate blade linkage	N/A
☐	14.7 Lubricate boom & stick linkage	N/A
☐	14.8 Lubricate swing bearing	N/A

PM OPERATOR STATION

☐	15.1 Check all doors for correct opening and closing adjustments and operation	MONITOR
☒	15.2 Inspect condition of door seals	PASS
☐	15.3 Check window glass and seal condition	N/A
☐	15.4 Check mirror condition and adjustments	N/A
☐	15.5 Fill window washer reservoir	N/A
☐	15.6 Inspect air con vents condition	N/A
☒	15.7 Inspect seat belt and mounting hardware	PASS

15.8 Inspect seat condition, operation and mounting	PASS
---	------

15.9 Replace cabin A/C filter	N/A
-------------------------------	-----

OIL SAMPLING

16.1 Engine	PASS
-------------	------

PM POST SERVICE INSPECTION CHECKS

17.1 All inspections have been completed and rectified as required	PASS
--	------

17.2 All safety related defects have been repaired or reported	PASS
--	------

17.3 All defects have been noted and reported	PASS
---	------

17.4 All fluids are at correct level and drain plugs tight	PASS
--	------

17.5 All oil samples have visually been inspected and any notable signs of contamination have been reported	PASS
---	------

17.6 All replaced filters have been cut and inspected and photos added to CAT Inspect and reported to supervisor	N/A
--	-----

17.7 Machine has been recommissioned and ready for operation	PASS
--	------

17.8 PM service notification marked off in Vision Link	N/A
--	-----

DEFECTS IDENTIFIED

18.1 DEFECTS IDENTIFIED	rhs door latch lock failed, rhs door gas strut requires new rose joint
-------------------------	--

OIL USED

19.1 Hydraulic oil	1
--------------------	---

19.2 Engine oil	12
-----------------	----

19.3 Slew oil	0
---------------	---

19.4 Gear oil	0
---------------	---

19.5 Coolant	0
--------------	---