

Safe Operating Procedures

Make: Ausa
Model: D1000 APG
Type: Dump Truck - Site
Plant Number: AHS71
Serial Number: 63180179



Recommended PPE - Subject to Company & Site Policy



SOP Dump Truck - Site

GENERAL & START UP

- Read and understand manufacturer's operational manual
- Complete pre-operational checklist (never use faulty or defective machinery)
- All operators must be free from the direct and after effects of drugs and alcohol
- Ensure that an appropriate, charged fire extinguisher is available
- Know your site dumper, its features and how they work. Keep your machine in good condition
- Ensure work area is clear of all bystanders and hazards prior to starting engine and operating machine
- Always ensure all guards are securely fitted prior to start up
- Once engine is started confirm control pattern and machine function

TRAVEL & OPERATION

- ! ALWAYS** WEAR YOUR SEAT BELT
- ! NEVER** USE MOBILE PHONE WHILE OPERATING MACHINE
- ! NEVER** CARRY PASSENGERS

- Always mount and dismount the machine at locations that have steps and/or handholds, maintain 3 points of contact at all times
- Ensure front and rear swing area is clear of bystanders and objects
- Avoid hard or sudden braking, especially when loaded
- Refer to power line approach distance label re safety around power lines
- Always stay alert and look for holes and other hidden hazards, especially when operating off road
- Do not dismount from site dumper unless engine is stopped, the transmission is in park position and the parking brake is effectively engaged
- Stay Alert! Watch what you are doing. Use common sense. Do not operate when you are tired

ROLLOVER HAZARD

- ALWAYS** use extreme caution when driving adjacent excavations and batter edges
- NEVER** POSITION MACHINE OVER "SHELF" ADJACENT EXCAVATION
- NEVER** move truck while tipping body is elevated unless in crawl gear on level surfaces
- NEVER** operate tipping body under precipice or overhead obstructions
- NEVER** travel across slopes, travel up and down slopes only

When stopping the dumper, park on even ground, shift the gear selector to park position and apply the parking brake, turn off the ignition and remove the keys

TRANSPORT & MAINTENANCE

- ALWAYS** switch off and isolate machine prior to performing any maintenance or transportation
- ALWAYS** employ safety prop prior to accessing area under raised tipping body

REFUELLING

- NEVER** refuel unless the engine is stopped and ignition turned off
- NEVER** smoke during refueling

Operator Signature:

Name: _____ Date: _____ Signature: _____