



**Australian Hammer Supplies Hire**  
Unit 3/32 Williamson Road  
Ingleburn  
NSW 2565

## KOBELCO SK210LC

### Major Service

0 0 0 0


|                   |                                                                                     |                  |                                    |
|-------------------|-------------------------------------------------------------------------------------|------------------|------------------------------------|
| Inspection Number | RP056579                                                                            | Customer No      | 200000                             |
| Serial Number     | YQ15405672                                                                          | Customer Name    | AUSTRALIAN HAMMER<br>SUPPLIES HIRE |
| Make              | KOBELCO                                                                             | Customer Email   |                                    |
| Model             | SK210LC                                                                             | Works Order      | RP056579                           |
| Equipment Family  | 17.1-22.5T HYDRAULIC EXCAVATOR                                                      | Completed On     | 14/01/2026 8:24:25 AM              |
| Asset ID          | AHSH148                                                                             | Inspector        | Etienne Llanos                     |
| Location          | AUSTRALIAN HAMMER SUPPLIES HIRE<br>Unit 3/32 WILLIAMSON RD<br><br>INGLEBURN<br>2565 | PDF Generated On | 14/01/2026                         |
|                   |                                                                                     | Machine Hours    | 3592                               |
|                   |                                                                                     | Next Meter       | 3599                               |
| Customer          |   |                  |                                    |

|                       |                                    |      |
|-----------------------|------------------------------------|------|
| <input type="radio"/> | Change inner air filter            | no   |
| <input type="radio"/> | Change hydraulic return filter     | yes  |
| <input type="radio"/> | Change hydraulic suction filter    | no   |
| <input type="radio"/> | Change hydraulic pilot filter      | no   |
| <input type="radio"/> | Take hydraulic oil sample          | no   |
| <input type="radio"/> | Change hydraulic oil (litres used) | 0    |
| <input type="radio"/> | Change engine oil (litres used)    | 22.5 |

### General Info & Comments

## General Info/Comments

500 at 3592



### TASK SAFETY INSTRUCTIONS

- |                                                                                  |      |
|----------------------------------------------------------------------------------|------|
| 1.1 Wear Correct PPE at all times                                                | PASS |
| 1.2 All isolation and safe work procedures must be followed                      | PASS |
| 1.3 Identify task hazards and controls utilising hierarchy or controls model     | PASS |
| 1.4 Ensure a competent operator and spotter is utilised to move mobile equipment | PASS |
| 1.5 Ensure all mobile equipment is fundamentally stable                          | PASS |
| 1.6 Ensure three points of contact is maintained during access and egress        | PASS |
| 1.7 Ensure acceptable housekeeping standards are maintained at all times         | PASS |

### MACHINE GENERAL RUNNINGCHECKS

- |                                                                                   |      |
|-----------------------------------------------------------------------------------|------|
| 2.1 Check all work lights, beacon & reverse alarmfor operation                    | PASS |
| 2.2 Test all dash warning lights, gauges and audible alarms for correct operation | PASS |
| 2.3 Check idle timer for correct shut down operation                              | PASS |
| 2.4 Check operation of all three emergency stop buttons                           | PASS |
| 2.5 Check operation of horn                                                       | PASS |
| 2.6 Check operation of reverse camera                                             | PASS |
| 2.7 Check alternator charge voltage                                               | PASS |

- |                                                                         |     |
|-------------------------------------------------------------------------|-----|
| ● 2.8 Check operation of auto grease systemby manually activating timer | N/A |
| ● 2.9 Check fire systemcontrol panel for 'Normal'                       | N/A |

#### PM FIRE SUPPRESSION SYSTEM

- |                                                                                                |                                  |
|------------------------------------------------------------------------------------------------|----------------------------------|
| ● 5.1 Ensure fire suppression bottle and components are securely mounted and in good condition | N/A                              |
| ● 5.2 Ensure fire suppression is correctly charged                                             | N/A                              |
| ● 5.3 Inspect last charge date                                                                 | DATE:2026-01-14T00:00:00.0000000 |
| ● 5.4 Check all fire extinguishers are securely mounted and in good condition                  | PASS                             |
| ● 5.5 Check all fire extinguishers are correctly charged                                       | PASS                             |
| ● 5.6 Inspect last charge date                                                                 | DATE:2026-01-14T00:00:00.0000000 |

#### PM ENGINE

- |                                                                               |      |
|-------------------------------------------------------------------------------|------|
| ● 6.1 Performengine valve set                                                 | N/A  |
| ● 6.2 Inspect air intake systemhoses, pipes, clamps for signs of dirt ingress | PASS |
| ● 6.3 Inspect engine for oil or fuel leaks                                    | PASS |
| ● 6.4 Inspect engine components for missing clamps                            | PASS |
| ● 6.5 Inspect exhaust systemfor signs of leaks, loose bolts or missing clamps | PASS |
| ● 6.6 Inspect turbo for security and signs of leaks                           | PASS |
| ● 6.7 Inspect condition of exhaust lagging                                    | PASS |
| ● 6.8 Inspect engine mounts for condition and loose hardware                  | PASS |
| ● 6.9 Inspect alternator mount condition and adjustment                       | PASS |
| ● 6.10 Inspect wiring condition and security                                  | PASS |
| ● 6.11 Inspect engine belts                                                   | PASS |

## PM ENGINE COOLINGSYSTEM

|                                                |      |
|------------------------------------------------|------|
| ● 7.1 Check coolant level                      | PASS |
| ● 7.2 Check condition of radiator cap          | PASS |
| ● 7.3 Check condition of radiator core         | PASS |
| ● 7.4 Check cooling system for signs of leaks  | PASS |
| ● 7.5 Check hose and clamp condition           | PASS |
| ● 7.6 Inspect fan condition and operation      | PASS |
| ● 7.7 Inspect radiator and fan guard condition | PASS |

## PM SWINGTRANSMISSION

|                                                     |      |
|-----------------------------------------------------|------|
| ● 8.1 Inspect swing transmission for signs of leaks | PASS |
| ● 8.2 Inspect swing transmission oil level          | PASS |

## PM HYDRAULIC SYSTEM

|                                                                                                                         |      |
|-------------------------------------------------------------------------------------------------------------------------|------|
| ● 9.1 Check hydraulic oil level                                                                                         | PASS |
| ● 9.2 Inspect hydraulic cylinders for leaks and security                                                                | PASS |
| ● 9.3 Inspect hydraulic hoses for leaks, damage, security                                                               | PASS |
| ● 9.4 Inspect hydraulic pump condition, leaks, security                                                                 | PASS |
| ● 9.5 Check Pilot Accumulator operation as per OEM Maintenance Procedure - Test Boom Down Functionality with engine off | PASS |

## PM FINAL DRIVES

|                                                                       |      |
|-----------------------------------------------------------------------|------|
| ● 10.1 Inspect LHS final drive mount condition for leaks and security | PASS |
| ● 10.2 Inspect LHS oil level and mag plug condition                   | PASS |
| ● 10.3 Inspect RHS final drive mount condition for leaks and security | PASS |
| ● 10.4 Inspect RHS oil level and mag plug condition                   | PASS |

## PM UNDERCARRIAGE

|                                                                 |      |
|-----------------------------------------------------------------|------|
| ● 11.1 Inspect LHS track tension                                | PASS |
| ● 11.2 Inspect RHS track tension                                | PASS |
| ● 11.3 Inspect tracks for loose/missing bolts                   | PASS |
| ● 11.4 Inspect load and carrier rollers for signs of leaks      | PASS |
| ● 11.5 Inspect idlers for signs of leaks                        | PASS |
| ● 11.6 Inspect sprocket segments condition                      | PASS |
| ● 11.7 Inspect track frame for cracks, lose or missing hardware | PASS |

## PM FRAME AND BODY

|                                                                                                         |      |
|---------------------------------------------------------------------------------------------------------|------|
| ● 12.1 Check panels for damage and security                                                             | PASS |
| ● 12.2 Check access steps and walkway condition                                                         | PASS |
| ● 12.3 Inspect boom condition – cracks, missing clamps, damaged pipes, excessive movement, lubrication  | PASS |
| ● 12.4 Inspect stick condition – cracks, missing clamps, damaged pipes, excessive movement, lubrication | PASS |
| ● 12.5 Inspect quick hitch condition and operation                                                      | PASS |
| ● 12.6 Inspect bucket condition – cracks, wear, damage, mounts                                          | PASS |
| ● 12.7 Inspect GET condition and hardware                                                               | PASS |

## PM ELECTRICAL SYSTEM

|                                            |      |
|--------------------------------------------|------|
| ● 13.1 Check battery condition             | PASS |
| ● 13.2 Check battery terminal condition    | PASS |
| ● 13.3 Check battery security              | PASS |
| ● 13.4 Check battery box drain is clear    | PASS |
| ● 13.5 Check wiring condition and security | PASS |

## PM GREASE SYSTEM

|   |                                                  |      |
|---|--------------------------------------------------|------|
| ● | 14.1 Check all points for acceptable lubrication | PASS |
| ● | 14.2 Inspect grease system operation             | N/A  |
| ● | 14.3 Check grease line condition                 | PASS |
| ● | 14.4 Refill grease tank                          | N/A  |
| ● | 14.5 Lubricate bucket linkage                    | PASS |
| ● | 14.6 Lubricate blade linkage                     | N/A  |
| ● | 14.7 Lubricate boom & stick linkage              | PASS |
| ● | 14.8 Lubricate swing bearing                     | PASS |

## PM OPERATOR STATION

|   |                                                                                |        |
|---|--------------------------------------------------------------------------------|--------|
| ● | 15.1 Check all doors for correct opening and closing adjustments and operation | FAIL   |
| ● | 15.2 Inspect condition of door seals                                           | PASS   |
| ● | 15.3 Check window glass and seal condition                                     | PASS   |
| ● | 15.4 Check mirror condition and adjustments                                    | PASS   |
| ● | 15.5 Fill window washer reservoir                                              | PASS   |
| ● | 15.6 Inspect air con vents condition                                           | PASS   |
| ● | 15.7 Inspect seat belt and mounting hardware                                   | PASS   |
| ● | 15.8 Inspect seat condition, operation and mounting                            | PASS   |
| ● | 15.9 Replace cabin A/C filter                                                  | NORMAL |

## OIL SAMPLING

|   |             |      |
|---|-------------|------|
| ● | 16.1 Engine | PASS |
|---|-------------|------|

## PM POST SERVICE INSPECTION CHECKS

|   |                                                                    |      |
|---|--------------------------------------------------------------------|------|
| ● | 17.1 All inspections have been completed and rectified as required | PASS |
|---|--------------------------------------------------------------------|------|

|   |                                                                                                                  |      |
|---|------------------------------------------------------------------------------------------------------------------|------|
| ● | 17.2 All safety related defects have been repaired or reported                                                   | PASS |
| ● | 17.3 All defects have been noted and reported                                                                    | PASS |
| ● | 17.4 All fluids are at correct level and drain plugs tight                                                       | PASS |
| ● | 17.5 All oil samples have visually been inspected and any notable signs of contamination have been reported      | N/A  |
| ● | 17.6 All replaced filters have been cut and inspected and photos added to CAT Inspect and reported to supervisor | N/A  |
| ● | 17.7 Machine has been recommissioned and ready for operation                                                     | PASS |
| ● | 17.8 PM service notification marked off in Vision Link                                                           | N/A  |

#### DEFECTS IDENTIFIED

|   |                         |                                         |
|---|-------------------------|-----------------------------------------|
| ● | 18.1 DEFECTS IDENTIFIED | <i>hitch cylinder weeping - monitor</i> |
|---|-------------------------|-----------------------------------------|

#### OIL USED

|   |                    |      |
|---|--------------------|------|
| ● | 19.1 Hydraulic oil | 0    |
| ● | 19.2 Engine oil    | 22.5 |
| ● | 19.3 Slew oil      | 0    |
| ● | 19.4 Gear oil      | 8    |
| ● | 19.5 Coolant       | 0    |