FITFLEET-EXCAVATOR-250HR-CVA

PM Checklist

● 0 ● 0 ● 96 ● 9

Inspection Number	18628037	Customer No	2969824372
Serial Number	JFW22078	Customer Name	AUSTRALIAN HAMMER SUPPLIES HIRE PTY LTD
Make	CATERPILLAR	Customer Email	hirebookings2@hammerhire.com.au
Model	336 GC	Work Order	sc71608
Equipment Family	Large Hydraulic Excavator	Completed On	16/08/2024 1:17:20 PM
Asset ID	AHSH155	Inspector	Collin Graham
SMU	2208.87 Hours	PDF Generated On	16/08/2024
Location	2nd Av, Banksmeadow, New South Wales 2036, Australia	Coordinates	0, 0, 0
Technician			

General Info & Comments

General info/Comments

NORMAL







TASK SAFETY INSTRUCTIONS - Revision Number: 02 Date: 25th September 2023

1.1 Wear Correct PPE at all times	*PASS*
1.2 All isolation and safe work procedures must be followed	*PASS*
1.3 Identify task hazards and controls utilising hierarchy or controls model	*PASS*
1.4 Ensure a competent operator and spotter is utilised to move mobile equipment	*PASS*
1.5 Ensure all mobile equipment is fundamentally stable	*PASS*
1.6 Ensure three points of contact is maintained during access and egress	*PASS*
1.7 Ensure acceptable housekeeping standards are maintained at all times	*PASS*

MACHINE GENERAL RUNNING CHECKS

2.1 Check all work lights, beacon & reverse alarm for operation	*PASS*
2.2 Test all dash warning lights, gauges and audible alarms for correct operation	*PASS*
2.3 Check idle timer for correct shut down operation	*PASS*
2.4 Check operation of all three emergency stop buttons	*PASS*
2.5 Check operation of horn	*PASS*

●	2.6 Check operation of reverse camera	*PASS*
●	2.7 Check alternator charge voltage - ACTUAL_____V	*PASS*
●	2.8 Check operation of auto grease system by manually activating timer	*N/A*
●	2.9 Check fire system control panel for 'Normal'	*N/A*
●	2.10 Test hydraulic lock out function operation	*PASS*
●	2.11 Check window wiper and washer operation	*PASS*

PM SAFETY GENERAL INSPECTION

●	3.1 Visually ensure all guards, shields and covers are in place and in good condition to ensure personal are protected from rotating parts	*PASS*
●	3.2 Check condition of machine identification signage	*PASS*
●	3.3 Inspect ROPS/FOPS condition	*PASS*

PM BRAKING SYSTEM

●	4.1 Test travel brakes – Ensure the machine comes to a stop when travel controls are released	*PASS*
●	4.2 Test travel brakes – Ensure the brakes hold on a suitable slope	*PASS*

PM FIRE SUPPRESSION SYSTEM

●	5.1 Ensure fire suppression bottle and components are securely mounted and in good condition	*N/A*
●	5.2 Ensure fire suppression is correctly charged	*N/A*
●	5.3 Inspect last charge date - ACTUAL _____	*N/A*
●	5.4 Check all fire extinguishers are securely mounted and in good condition	*PASS*

5.5 Check all fire extinguishers are correctly charged	*PASS*
5.6 Inspect last charge date - ACTUAL _____	*PASS*

PM ENGINE

6.1 Perform engine valve set	*N/A*
6.2 Inspect air intake system hoses, pipes, clamps for signs of dirt ingress	*PASS*
6.3 Inspect engine for oil or fuel leaks	*PASS*
6.4 Inspect engine components for missing clamps	*PASS*
6.5 Inspect exhaust system for signs of leaks, loose bolts or missing clamps	*PASS*
6.6 Inspect turbo for security and signs of leaks	*PASS*
6.7 Inspect condition of exhaust lagging	*PASS*
6.8 Inspect engine mounts for condition and loose hardware	*PASS*
6.9 Inspect alternator mount condition and adjustment	*PASS*
6.10 Inspect wiring condition and security	*PASS*
6.11 Inspect engine belts	*PASS*

PM ENGINE COOLING SYSTEM

7.1 Check coolant level	*PASS*
7.2 Check condition of radiator cap	*PASS*
7.3 Check condition of radiator core	*PASS*

7.4 Check cooling system for signs of leaks	*PASS*
7.5 Check hose and clamp condition	*PASS*
7.6 Inspect fan condition and operation	*PASS*
7.7 Inspect radiator and fan guard condition	*PASS*

PM SWING TRANSMISSION

8.1 Inspect swing transmission for signs of leaks	*PASS*
8.2 Inspect swing transmission oil level	*PASS*

PM HYDRAULIC SYSTEM

9.1 Check hydraulic oil level	*PASS*
9.2 Inspect hydraulic cylinders for leaks and security	*PASS*
9.3 Inspect hydraulic hoses for leaks, damage, security	*PASS*
9.4 Inspect hydraulic pump condition, leaks, security	*PASS*
9.5 Check Pilot Accumulator operation as per OEM Maintenance Procedure - Test Boom Down Functionality with engine off	*PASS*

PM FINAL DRIVES

10.1 Inspect LHS final drive mount condition for leaks and security	*PASS*
10.2 Inspect LHS oil level and mag plug condition	*PASS*
10.3 Inspect RHS final drive mount condition for leaks and security	*PASS*
10.4 Inspect RHS oil level and mag plug condition	*PASS*

PM UNDERCARRIAGE

11.1 Inspect LHS track tension	*PASS*
11.2 Inspect RHS track tension	*PASS*
11.3 Inspect tracks for loose/missing bolts	*PASS*
11.4 Inspect load and carrier rollers for signs of leaks	*PASS*
11.5 Inspect idlers for signs of leaks	*PASS*
11.6 Inspect sprocket segments condition	*PASS*
11.7 Inspect track frame for cracks, lose or missing hardware	*PASS*

PM FRAME AND BODY

12.1 Check panels for damage and security	*PASS*
12.2 Check access steps and walkway condition	*PASS*
12.3 Inspect boom condition – cracks, missing clamps, damaged pipes, excessive movement, lubrication	*PASS*
12.4 Inspect stick condition – cracks, missing clamps, damaged pipes, excessive movement, lubrication	*PASS*
12.5 Inspect quick hitch condition and operation	*PASS*
12.6 Inspect bucket condition – cracks, wear, damage, mounts	*PASS*
12.7 Inspect GET condition and hardware	*PASS*

PM ELECTRICAL SYSTEM

13.1 Check battery condition	*PASS*

13.2 Check battery terminal condition	*PASS*
13.3 Check battery security	*PASS*
13.4 Check battery box drain is clear	*PASS*
13.5 Check wiring condition and security	*PASS*

PM GREASE SYSTEM

14.1 Check all points for acceptable lubrication	*PASS*
14.2 Inspect grease system operation	*N/A*
14.3 Check grease line condition	*PASS*
14.4 Refill grease tank	*N/A*
14.5 Lubricate bucket linkage	*PASS*
14.6 Lubricate blade linkage	*PASS*
14.7 Lubricate boom & stick linkage	*PASS*
14.8 Lubricate swing bearing	*PASS*

PM OPERATOR STATION

15.1 Check all doors for correct opening and closing adjustments and operation	*PASS*
15.2 Inspect condition of door seals	*PASS*
15.3 Check window glass and seal condition	*PASS*
15.4 Check mirror condition and adjustments	*PASS*

15.5 Fill window washer reservoir	*PASS*
15.6 Inspect air con vents condition	*PASS*
15.7 Inspect seat belt and mounting hardware	*PASS*
15.8 Inspect seat condition, operation and mounting	*PASS*
15.9 Replace cabin A/C filter	*N/A*

OIL SAMPLING

16.1 Engine	*PASS*

PM POST SERVICE INSPECTION CHECKS

17.1 All inspections have been completed and rectified as required	*PASS*
17.2 All safety related defects have been repaired or reported	*PASS*
17.3 All defects have been noted and reported	*PASS*
17.4 All fluids are at correct level and drain plugs tight	*PASS*
17.5 All oil samples have visually been inspected and any notable signs of contamination have been reported	*PASS*
17.6 All replaced filters have been cut and inspected and photos added to CAT Inspect and reported to supervisor	*PASS*
17.7 Machine has been recommissioned and ready for operation	*PASS*
17.8 PM service notification marked off in Vision Link	*COMPLETED*

DEFECTS IDENTIFIED

18.1 DEFECTS IDENTIFIED	*PASS*