



Australian Hammer Supplies Hire  
Unit 3/32 Williamson Road  
Ingleburn  
NSW 2565

CATERPILLAR CAT335F




Major Service 0 14 91 3

|                   |                                                                                     |                  |                                 |
|-------------------|-------------------------------------------------------------------------------------|------------------|---------------------------------|
| Inspection Number | RP054418                                                                            | Customer No      | 200000                          |
| Serial Number     | SGJ20461                                                                            | Customer Name    | AUSTRALIAN HAMMER SUPPLIES HIRE |
| Make              | CATERPILLAR                                                                         | Customer Email   |                                 |
| Model             | CAT335F                                                                             | Works Order      | RP054418                        |
| Equipment Family  | 35.1-40T HYDRAULIC EXCAVATOR                                                        | Completed On     | 4/11/2025 1:20:32 PM            |
| Asset ID          | AHSH160                                                                             | Inspector        | Collin Graham                   |
| Location          | AUSTRALIAN HAMMER SUPPLIES HIRE<br>Unit 3/32 WILLIAMSON RD<br><br>INGLEBURN<br>2565 | PDF Generated On | 04/11/2025                      |
|                   |                                                                                     | Machine Hours    |                                 |
| Customer          |   | Next Meter       | 7934                            |

General Info & Comments

## General Info/Comments

major service



## TASK SAFETY INSTRUCTIONS

|                                                                                  |      |
|----------------------------------------------------------------------------------|------|
| 1.1 Wear Correct PPE at all times                                                | PASS |
| 1.2 All isolation and safe work procedures must be followed                      | PASS |
| 1.3 Identify task hazards and controls utilising hierarchy or controls model     | PASS |
| 1.4 Ensure a competent operator and spotter is utilised to move mobile equipment | PASS |
| 1.5 Ensure all mobile equipment is fundamentally stable                          | PASS |
| 1.6 Ensure three points of contact is maintained during access and egress        | PASS |
| 1.7 Ensure acceptable housekeeping standards are maintained at all times         | PASS |

## MACHINE GENERAL RUNNINGCHECKS

|   |                                                                                   |      |
|---|-----------------------------------------------------------------------------------|------|
| ● | 2.1 Check all work lights, beacon & reverse alarm for operation                   | PASS |
| ● | 2.2 Test all dash warning lights, gauges and audible alarms for correct operation | PASS |
| ● | 2.3 Check idle timer for correct shut down operation                              | PASS |
| ● | 2.4 Check operation of all three emergency stop buttons                           | PASS |
| ● | 2.5 Check operation of horn                                                       | PASS |
| ● | 2.6 Check operation of reverse camera                                             | PASS |
| ● | 2.7 Check alternator charge voltage                                               | PASS |
| ● | 2.8 Check operation of auto grease system by manually activating timer            | N/A  |
| ● | 2.9 Check fire system control panel for 'Normal'                                  | PASS |

#### PM FIRE SUPPRESSION SYSTEM

|   |                                                                                              |                                 |
|---|----------------------------------------------------------------------------------------------|---------------------------------|
| ● | 5.1 Ensure fire suppression bottle and components are securely mounted and in good condition | PASS                            |
| ● | 5.2 Ensure fire suppression is correctly charged                                             | PASS                            |
| ● | 5.3 Inspect last charge date                                                                 | DATE:2025-11-04T00:00:00.000000 |
| ● | 5.4 Check all fire extinguishers are securely mounted and in good condition                  | PASS                            |
| ● | 5.5 Check all fire extinguishers are correctly charged                                       | PASS                            |
| ● | 5.6 Inspect last charge date                                                                 | DATE:2025-11-04T00:00:00.000000 |

#### PM ENGINE

|   |                                                                              |      |
|---|------------------------------------------------------------------------------|------|
| ● | 6.1 Perform engine valve set                                                 | N/A  |
| ● | 6.2 Inspect air intake system hoses, pipes, clamps for signs of dirt ingress | PASS |
| ● | 6.3 Inspect engine for oil or fuel leaks                                     | PASS |
| ● | 6.4 Inspect engine components for missing clamps                             | PASS |

|                                                                               |      |
|-------------------------------------------------------------------------------|------|
| ● 6.5 Inspect exhaust systemfor signs of leaks, loose bolts or missing clamps | PASS |
| ● 6.6 Inspect turbo for security and signs of leaks                           | PASS |
| ● 6.7 Inspect condition of exhaust lagging                                    | PASS |
| ● 6.8 Inspect engine mounts for condition and loose hardware                  | PASS |
| ● 6.9 Inspect alternator mount condition and adjustment                       | PASS |
| ● 6.10 Inspect wiring condition and security                                  | PASS |
| ● 6.11 Inspect engine belts                                                   | PASS |

## PM ENGINE COOLINGSYSTEM

|                                                |      |
|------------------------------------------------|------|
| ● 7.1 Check coolant level                      | PASS |
| ● 7.2 Check condition of radiator cap          | PASS |
| ● 7.3 Check condition of radiator core         | PASS |
| ● 7.4 Check cooling systemfor signs of leaks   | PASS |
| ● 7.5 Check hose and clamp condition           | PASS |
| ● 7.6 Inspect fan condition and operation      | PASS |
| ● 7.7 Inspect radiator and fan guard condition | PASS |

## PM SWINGTRANSMISSION

|                                                     |      |
|-----------------------------------------------------|------|
| ● 8.1 Inspect swing transmission for signs of leaks | PASS |
| ● 8.2 Inspect swing transmission oil level          | PASS |

## PM HYDRAULIC SYSTEM

|                                                           |      |
|-----------------------------------------------------------|------|
| ● 9.1 Check hydraulic oil level                           | PASS |
| ● 9.2 Inspect hydraulic cylinders for leaks and security  | PASS |
| ● 9.3 Inspect hydraulic hoses for leaks, damage, security | PASS |
| ● 9.4 Inspect hydraulic pump condition, leaks, security   | PASS |

- |   |                                                                                                                              |             |
|---|------------------------------------------------------------------------------------------------------------------------------|-------------|
| ● | <b>9.5 Check Pilot Accumulator operation as per OEM Maintenance Procedure - Test Boom Down Functionality with engine off</b> | <i>PASS</i> |
|---|------------------------------------------------------------------------------------------------------------------------------|-------------|

## PM FINAL DRIVES

- |   |                                                                            |             |
|---|----------------------------------------------------------------------------|-------------|
| ● | <b>10.1 Inspect LHS final drive mount condition for leaks and security</b> | <i>PASS</i> |
| ● | <b>10.2 Inspect LHS oil level and mag plug condition</b>                   | <i>PASS</i> |
| ● | <b>10.3 Inspect RHS final drive mount condition for leaks and security</b> | <i>PASS</i> |
| ● | <b>10.4 Inspect RHS oil level and mag plug condition</b>                   | <i>PASS</i> |

## PM UNDERCARRIAGE

- |   |                                                                      |             |
|---|----------------------------------------------------------------------|-------------|
| ● | <b>11.1 Inspect LHS track tension</b>                                | <i>PASS</i> |
| ● | <b>11.2 Inspect RHS track tension</b>                                | <i>PASS</i> |
| ● | <b>11.3 Inspect tracks for loose/missing bolts</b>                   | <i>PASS</i> |
| ● | <b>11.4 Inspect load and carrier rollers for signs of leaks</b>      | <i>PASS</i> |
| ● | <b>11.5 Inspect idlers for signs of leaks</b>                        | <i>PASS</i> |
| ● | <b>11.6 Inspect sprocket segments condition</b>                      | <i>PASS</i> |
| ● | <b>11.7 Inspect track frame for cracks, lose or missing hardware</b> | <i>PASS</i> |

## PM FRAME AND BODY

- |   |                                                                                                              |             |
|---|--------------------------------------------------------------------------------------------------------------|-------------|
| ● | <b>12.1 Check panels for damage and security</b>                                                             | <i>PASS</i> |
| ● | <b>12.2 Check access steps and walkway condition</b>                                                         | <i>PASS</i> |
| ● | <b>12.3 Inspect boom condition – cracks, missing clamps, damaged pipes, excessive movement, lubrication</b>  | <i>PASS</i> |
| ● | <b>12.4 Inspect stick condition – cracks, missing clamps, damaged pipes, excessive movement, lubrication</b> | <i>PASS</i> |
| ● | <b>12.5 Inspect quick hitch condition and operation</b>                                                      | <i>PASS</i> |
| ● | <b>12.6 Inspect bucket condition – cracks, wear, damage, mounts</b>                                          | <i>PASS</i> |
| ● | <b>12.7 Inspect GET condition and hardware</b>                                                               | <i>PASS</i> |

## PM ELECTRICAL SYSTEM

|                                            |      |
|--------------------------------------------|------|
| ● 13.1 Check battery condition             | PASS |
| ● 13.2 Check battery terminal condition    | PASS |
| ● 13.3 Check battery security              | PASS |
| ● 13.4 Check battery box drain is clear    | PASS |
| ● 13.5 Check wiring condition and security | PASS |

## PM GREASE SYSTEM

|                                                    |      |
|----------------------------------------------------|------|
| ● 14.1 Check all points for acceptable lubrication | PASS |
| ● 14.2 Inspect grease system operation             | PASS |
| ● 14.3 Check grease line condition                 | PASS |
| ● 14.4 Refill grease tank                          | N/A  |
| ● 14.5 Lubricate bucket linkage                    | PASS |
| ● 14.6 Lubricate blade linkage                     | PASS |
| ● 14.7 Lubricate boom & stick linkage              | PASS |
| ● 14.8 Lubricate swing bearing                     | PASS |

## PM OPERATOR STATION

|                                                                                  |      |
|----------------------------------------------------------------------------------|------|
| ● 15.1 Check all doors for correct opening and closing adjustments and operation | PASS |
| ● 15.2 Inspect condition of door seals                                           | PASS |
| ● 15.3 Check window glass and seal condition                                     | PASS |
| ● 15.4 Check mirror condition and adjustments                                    | PASS |
| ● 15.5 Fill window washer reservoir                                              | PASS |
| ● 15.6 Inspect air con vents condition                                           | PASS |
| ● 15.7 Inspect seat belt and mounting hardware                                   | PASS |

|                                                       |      |
|-------------------------------------------------------|------|
| ● 15.8 Inspect seat condition, operation and mounting | PASS |
|-------------------------------------------------------|------|

|                                 |      |
|---------------------------------|------|
| ● 15.9 Replace cabin A/C filter | PASS |
|---------------------------------|------|

#### OIL SAMPLING

|               |      |
|---------------|------|
| ● 16.1 Engine | PASS |
|---------------|------|

#### PM POST SERVICE INSPECTION CHECKS

|                                                                      |      |
|----------------------------------------------------------------------|------|
| ● 17.1 All inspections have been completed and rectified as required | PASS |
|----------------------------------------------------------------------|------|

|                                                                  |      |
|------------------------------------------------------------------|------|
| ● 17.2 All safety related defects have been repaired or reported | PASS |
|------------------------------------------------------------------|------|

|                                                 |      |
|-------------------------------------------------|------|
| ● 17.3 All defects have been noted and reported | PASS |
|-------------------------------------------------|------|

|                                                              |      |
|--------------------------------------------------------------|------|
| ● 17.4 All fluids are at correct level and drain plugs tight | PASS |
|--------------------------------------------------------------|------|

|                                                                                                               |      |
|---------------------------------------------------------------------------------------------------------------|------|
| ● 17.5 All oil samples have visually been inspected and any notable signs of contamination have been reported | PASS |
|---------------------------------------------------------------------------------------------------------------|------|

|                                                                                                                    |      |
|--------------------------------------------------------------------------------------------------------------------|------|
| ● 17.6 All replaced filters have been cut and inspected and photos added to CAT Inspect and reported to supervisor | PASS |
|--------------------------------------------------------------------------------------------------------------------|------|

|                                                                |      |
|----------------------------------------------------------------|------|
| ● 17.7 Machine has been recommissioned and ready for operation | PASS |
|----------------------------------------------------------------|------|

|                                                          |      |
|----------------------------------------------------------|------|
| ● 17.8 PM service notification marked off in Vision Link | PASS |
|----------------------------------------------------------|------|

#### DEFECTS IDENTIFIED

|                           |    |
|---------------------------|----|
| ● 18.1 DEFECTS IDENTIFIED | na |
|---------------------------|----|

#### OIL USED

|                      |   |
|----------------------|---|
| ● 19.1 Hydraulic oil | 0 |
|----------------------|---|

|                   |    |
|-------------------|----|
| ● 19.2 Engine oil | 26 |
|-------------------|----|

|                 |   |
|-----------------|---|
| ● 19.3 Slew oil | 0 |
|-----------------|---|

|                 |   |
|-----------------|---|
| ● 19.4 Gear oil | 0 |
|-----------------|---|

|                |   |
|----------------|---|
| ● 19.5 Coolant | 1 |
|----------------|---|