



Australian Hammer Supplies Hire
Unit 3/32 Williamson Road
Ingleburn
NSW 2565

KUBOTA SVL75 SKID STEER LOADER


Major Service ● 0 ● 14 ● 82 ● 12

Inspection Number	RP053764	Customer No	200000
Serial Number	75030	Customer Name	AUSTRALIAN HAMMER SUPPLIES HIRE
Make	KUBOTA	Customer Email	
Model	SVL75-2C	Works Order	RP053764
Equipment Family	SKID STEER LOADER	Completed On	9/10/2025 6:48:36 AM
Asset ID	AHSH170	Inspector	Collin Graham
Location	CONO BERRY STREET NORTH SYDNEY	PDF Generated On	09/10/2025
		Machine Hours	1098
		Next Meter	1067
Customer			

General Info & Comments

General Info/Comments

1000hr service



TASK SAFETY INSTRUCTIONS

- | | |
|--|------|
| 1.1 Wear Correct PPE at all times | PASS |
| 1.2 All isolation and safe work procedures must be followed | PASS |
| 1.3 Identify task hazards and controls utilising hierarchy or controls model | PASS |
| 1.4 Ensure a competent operator and spotter is utilised to move mobile equipment | PASS |
| 1.5 Ensure all mobile equipment is fundamentally stable | PASS |
| 1.6 Ensure three points of contact is maintained during access and egress | PASS |
| 1.7 Ensure acceptable housekeeping standards are maintained at all times | PASS |

MACHINE GENERAL RUNNINGCHECKS

● 2.1 Check all work lights, beacon & reverse alarmfor operation	PASS
● 2.2 Test all dash warning lights, gauges and audible alarms for correct operation	PASS
● 2.3 Check idle timer for correct shut down operation	PASS
● 2.4 Check operation of all three emergency stop buttons	PASS
● 2.5 Check operation of horn	PASS
● 2.6 Check operation of reverse camera	PASS
● 2.7 Check alternator charge voltage	PASS
● 2.8 Check operation of auto grease systemby manually activating timer	N/A
● 2.9 Check fire systemcontrol panel for 'Normal'	N/A

PM FIRE SUPPRESSION SYSTEM

● 5.1 Ensure fire suppression bottle and components are securely mounted and in good condition	N/A
● 5.2 Ensure fire suppression is correctly charged	N/A
● 5.3 Inspect last charge date	DATE:2025-10-09T00:00:00.0000000
● 5.4 Check all fire extinguishers are securely mounted and in good condition	PASS
● 5.5 Check all fire extinguishers are correctly charged	PASS
● 5.6 Inspect last charge date	DATE:2025-09-09T00:00:00.0000000

PM ENGINE

● 6.1 Performengine valve set	N/A
● 6.2 Inspect air intake systemhoses, pipes, clamps for signs of dirt ingress	PASS
● 6.3 Inspect engine for oil or fuel leaks	PASS
● 6.4 Inspect engine components for missing clamps	PASS

● 6.5 Inspect exhaust systemfor signs of leaks, loose bolts or missing clamps	PASS
● 6.6 Inspect turbo for security and signs of leaks	PASS
● 6.7 Inspect condition of exhaust lagging	PASS
● 6.8 Inspect engine mounts for condition and loose hardware	PASS
● 6.9 Inspect alternator mount condition and adjustment	PASS
● 6.10 Inspect wiring condition and security	PASS
● 6.11 Inspect engine belts	PASS

PM ENGINE COOLINGSYSTEM

● 7.1 Check coolant level	PASS
● 7.2 Check condition of radiator cap	PASS
● 7.3 Check condition of radiator core	PASS
● 7.4 Check cooling systemfor signs of leaks	PASS
● 7.5 Check hose and clamp condition	PASS
● 7.6 Inspect fan condition and operation	PASS
● 7.7 Inspect radiator and fan guard condition	PASS

PM SWINGTRANSMISSION

● 8.1 Inspect swing transmission for signs of leaks	N/A
● 8.2 Inspect swing transmission oil level	N/A

PM HYDRAULIC SYSTEM

● 9.1 Check hydraulic oil level	PASS
● 9.2 Inspect hydraulic cylinders for leaks and security	PASS
● 9.3 Inspect hydraulic hoses for leaks, damage, security	PASS
● 9.4 Inspect hydraulic pump condition, leaks, security	PASS

- | | | |
|----------------------------------|---|------|
| ☒ | 9.5 Check Pilot Accumulator operation as per OEM Maintenance Procedure - Test Boom Down Functionality with engine off | PASS |
|----------------------------------|---|------|

PM FINAL DRIVES

- | | | |
|----------------------------------|---|------|
| ☒ | 10.1 Inspect LHS final drive mount condition for leaks and security | PASS |
| ☒ | 10.2 Inspect LHS oil level and mag plug condition | PASS |
| ☒ | 10.3 Inspect RHS final drive mount condition for leaks and security | PASS |
| ☒ | 10.4 Inspect RHS oil level and mag plug condition | PASS |

PM UNDERCARRIAGE

- | | | |
|----------------------------------|---|------|
| ☒ | 11.1 Inspect LHS track tension | PASS |
| ☒ | 11.2 Inspect RHS track tension | PASS |
| ☒ | 11.3 Inspect tracks for loose/missing bolts | PASS |
| ☒ | 11.4 Inspect load and carrier rollers for signs of leaks | PASS |
| ☒ | 11.5 Inspect idlers for signs of leaks | PASS |
| ☒ | 11.6 Inspect sprocket segments condition | PASS |
| ☒ | 11.7 Inspect track frame for cracks, lose or missing hardware | PASS |

PM FRAME AND BODY

- | | | |
|----------------------------------|---|------|
| ☒ | 12.1 Check panels for damage and security | PASS |
| ☒ | 12.2 Check access steps and walkway condition | PASS |
| ☒ | 12.3 Inspect boom condition – cracks, missing clamps, damaged pipes, excessive movement, lubrication | PASS |
| ☐ | 12.4 Inspect stick condition – cracks, missing clamps, damaged pipes, excessive movement, lubrication | N/A |
| ☒ | 12.5 Inspect quick hitch condition and operation | PASS |
| ☒ | 12.6 Inspect bucket condition – cracks, wear, damage, mounts | PASS |
| ☒ | 12.7 Inspect GET condition and hardware | PASS |

PM ELECTRICAL SYSTEM

☒	13.1 Check battery condition	PASS
☒	13.2 Check battery terminal condition	PASS
☒	13.3 Check battery security	PASS
☒	13.4 Check battery box drain is clear	PASS
☒	13.5 Check wiring condition and security	PASS

PM GREASE SYSTEM

☒	14.1 Check all points for acceptable lubrication	PASS
☒	14.2 Inspect grease system operation	PASS
☒	14.3 Check grease line condition	PASS
☐	14.4 Refill grease tank	N/A
☒	14.5 Lubricate bucket linkage	PASS
☐	14.6 Lubricate blade linkage	N/A
☒	14.7 Lubricate boom & stick linkage	PASS
☐	14.8 Lubricate swing bearing	N/A

PM OPERATOR STATION

☒	15.1 Check all doors for correct opening and closing adjustments and operation	PASS
☒	15.2 Inspect condition of door seals	PASS
☒	15.3 Check window glass and seal condition	PASS
☒	15.4 Check mirror condition and adjustments	PASS
☒	15.5 Fill window washer reservoir	PASS
☒	15.6 Inspect air con vents condition	PASS
☒	15.7 Inspect seat belt and mounting hardware	PASS

● 15.8 Inspect seat condition, operation and mounting	PASS
---	------

● 15.9 Replace cabin A/C filter	PASS
---------------------------------	------

OIL SAMPLING

● 16.1 Engine	PASS
---------------	------

PM POST SERVICE INSPECTION CHECKS

● 17.1 All inspections have been completed and rectified as required	PASS
--	------

● 17.2 All safety related defects have been repaired or reported	PASS
--	------

● 17.3 All defects have been noted and reported	PASS
---	------

● 17.4 All fluids are at correct level and drain plugs tight	PASS
--	------

● 17.5 All oil samples have visually been inspected and any notable signs of contamination have been reported	PASS
---	------

● 17.6 All replaced filters have been cut and inspected and photos added to CAT Inspect and reported to supervisor	PASS
--	------

● 17.7 Machine has been recommissioned and ready for operation	PASS
--	------

● 17.8 PM service notification marked off in Vision Link	N/A
--	-----

DEFECTS IDENTIFIED

● 18.1 DEFECTS IDENTIFIED	na
---------------------------	----

OIL USED

● 19.1 Hydraulic oil	25
----------------------	----

● 19.2 Engine oil	13
-------------------	----

● 19.3 Slew oil	0
-----------------	---

● 19.4 Gear oil	3
-----------------	---

● 19.5 Coolant	0
----------------	---



Australian Hammer Supplies Hire
Unit 3/32 Williamson Road
Ingleburn
NSW 2565

● Site photo

● Site photo

● Site photo

● Site photo

● Site photo

● Site photo

● Site photo

● Site photo

● Site photo

● Site photo

● Site photo