

KUBOTA MINI EXCAVATOR U17-3

Major Service

● 0 ● 11 ● 86 ● 8

| | | | |
|-------------------|--|------------------|---------------------------------|
| Inspection Number | RP052479 | Customer No | 200000 |
| Serial Number | 60385 | Customer Name | AUSTRALIAN HAMMER SUPPLIES HIRE |
| Make | KUBOTA | Customer Email | |
| Model | U17-3 | Works Order | RP052479 |
| Equipment Family | <2T HYDRAULIC EXCAVATOR | Completed On | 8/01/2026 3:19:29 PM |
| Asset ID | AHSH203 | Inspector | Reid Lewis |
| Location | AUSTRALIAN HAMMER SUPPLIES HIRE Unit 3/32 WILLIAMSON RD INGLEBURN 2565 | PDF Generated On | 08/01/2026 |
| | | Machine Hours | 993 |
| | | Next Meter | 1000 |
| Customer |  | | |

General Info & Comments

● General Info/Comments y

TASK SAFETY INSTRUCTIONS

- 1.1 Wear Correct PPE at all times PASS
- 1.2 All isolation and safe work procedures must be followed PASS
- 1.3 Identify task hazards and controls utilising hierarchy or controls model PASS
- 1.4 Ensure a competent operator and spotter is utilised to move mobile equipment PASS
- 1.5 Ensure all mobile equipment is fundamentally stable PASS
- 1.6 Ensure three points of contact is maintained during access and egress PASS
- 1.7 Ensure acceptable housekeeping standards are maintained at all times PASS

MACHINE GENERAL RUNNINGCHECKS

| | |
|---|------|
| ● 2.1 Check all work lights, beacon & reverse alarm for operation | PASS |
| ● 2.2 Test all dash warning lights, gauges and audible alarms for correct operation | PASS |
| ● 2.3 Check idle timer for correct shut down operation | PASS |
| ● 2.4 Check operation of all three emergency stop buttons | PASS |
| ● 2.5 Check operation of horn | PASS |
| ● 2.6 Check operation of reverse camera | PASS |
| ● 2.7 Check alternator charge voltage | PASS |
| ● 2.8 Check operation of auto grease system by manually activating timer | N/A |
| ● 2.9 Check fire system control panel for 'Normal' | N/A |

PM FIRE SUPPRESSION SYSTEM

| | |
|--|---------------------------------|
| ● 5.1 Ensure fire suppression bottle and components are securely mounted and in good condition | N/A |
| ● 5.2 Ensure fire suppression is correctly charged | N/A |
| ● 5.3 Inspect last charge date | DATE:2026-01-08T00:00:00.000000 |
| ● 5.4 Check all fire extinguishers are securely mounted and in good condition | PASS |
| ● 5.5 Check all fire extinguishers are correctly charged | PASS |
| ● 5.6 Inspect last charge date | DATE:2026-01-08T00:00:00.000000 |

PM ENGINE

| | |
|--|------|
| ● 6.1 Perform engine valve set | PASS |
| ● 6.2 Inspect air intake system hoses, pipes, clamps for signs of dirt ingress | PASS |
| ● 6.3 Inspect engine for oil or fuel leaks | PASS |
| ● 6.4 Inspect engine components for missing clamps | PASS |

- | | |
|--|------|
| ● 6.5 Inspect exhaust system for signs of leaks, loose bolts or missing clamps | PASS |
| ● 6.6 Inspect turbo for security and signs of leaks | PASS |
| ● 6.7 Inspect condition of exhaust lagging | PASS |
| ● 6.8 Inspect engine mounts for condition and loose hardware | PASS |
| ● 6.9 Inspect alternator mount condition and adjustment | PASS |
| ● 6.10 Inspect wiring condition and security | PASS |
| ● 6.11 Inspect engine belts | PASS |

PM ENGINE COOLING SYSTEM

- | | |
|--|------|
| ● 7.1 Check coolant level | PASS |
| ● 7.2 Check condition of radiator cap | PASS |
| ● 7.3 Check condition of radiator core | PASS |
| ● 7.4 Check cooling system for signs of leaks | PASS |
| ● 7.5 Check hose and clamp condition | PASS |
| ● 7.6 Inspect fan condition and operation | PASS |
| ● 7.7 Inspect radiator and fan guard condition | PASS |

PM SWING TRANSMISSION

- | | |
|---|------|
| ● 8.1 Inspect swing transmission for signs of leaks | PASS |
| ● 8.2 Inspect swing transmission oil level | PASS |

PM HYDRAULIC SYSTEM

- | | |
|---|------|
| ● 9.1 Check hydraulic oil level | PASS |
| ● 9.2 Inspect hydraulic cylinders for leaks and security | PASS |
| ● 9.3 Inspect hydraulic hoses for leaks, damage, security | PASS |
| ● 9.4 Inspect hydraulic pump condition, leaks, security | PASS |

- 9.5 Check Pilot Accumulator operation as per OEM Maintenance Procedure - Test Boom Down Functionality with engine off *PASS*

PM FINAL DRIVES

- 10.1 Inspect LHS final drive mount condition for leaks and security *PASS*
- 10.2 Inspect LHS oil level and mag plug condition *PASS*
- 10.3 Inspect RHS final drive mount condition for leaks and security *PASS*
- 10.4 Inspect RHS oil level and mag plug condition *PASS*

PM UNDERCARRIAGE

- 11.1 Inspect LHS track tension *PASS*
- 11.2 Inspect RHS track tension *PASS*
- 11.3 Inspect tracks for loose/missing bolts *PASS*
- 11.4 Inspect load and carrier rollers for signs of leaks *PASS*
- 11.5 Inspect idlers for signs of leaks *PASS*
- 11.6 Inspect sprocket segments condition *PASS*
- 11.7 Inspect track frame for cracks, lose or missing hardware *PASS*

PM FRAME AND BODY

- 12.1 Check panels for damage and security *PASS*
- 12.2 Check access steps and walkway condition *PASS*
- 12.3 Inspect boom condition – cracks, missing clamps, damaged pipes, excessive movement, lubrication *PASS*
- 12.4 Inspect stick condition – cracks, missing clamps, damaged pipes, excessive movement, lubrication *PASS*
- 12.5 Inspect quick hitch condition and operation *PASS*
- 12.6 Inspect bucket condition – cracks, wear, damage, mounts *PASS*
- 12.7 Inspect GET condition and hardware *PASS*

PM ELECTRICAL SYSTEM

| | |
|---|------|
| <input checked="" type="radio"/> 13.1 Check battery condition | PASS |
| <input checked="" type="radio"/> 13.2 Check battery terminal condition | PASS |
| <input checked="" type="radio"/> 13.3 Check battery security | PASS |
| <input checked="" type="radio"/> 13.4 Check battery box drain is clear | PASS |
| <input checked="" type="radio"/> 13.5 Check wiring condition and security | PASS |

PM GREASE SYSTEM

| | |
|---|------|
| <input checked="" type="radio"/> 14.1 Check all points for acceptable lubrication | PASS |
| <input type="radio"/> 14.2 Inspect grease system operation | N/A |
| <input type="radio"/> 14.3 Check grease line condition | N/A |
| <input type="radio"/> 14.4 Refill grease tank | N/A |
| <input checked="" type="radio"/> 14.5 Lubricate bucket linkage | PASS |
| <input checked="" type="radio"/> 14.6 Lubricate blade linkage | PASS |
| <input checked="" type="radio"/> 14.7 Lubricate boom & stick linkage | PASS |
| <input checked="" type="radio"/> 14.8 Lubricate swing bearing | PASS |

PM OPERATOR STATION

| | |
|---|------|
| <input checked="" type="radio"/> 15.1 Check all doors for correct opening and closing adjustments and operation | PASS |
| <input checked="" type="radio"/> 15.2 Inspect condition of door seals | PASS |
| <input checked="" type="radio"/> 15.3 Check window glass and seal condition | PASS |
| <input checked="" type="radio"/> 15.4 Check mirror condition and adjustments | PASS |
| <input checked="" type="radio"/> 15.5 Fill window washer reservoir | PASS |
| <input checked="" type="radio"/> 15.6 Inspect air con vents condition | PASS |
| <input checked="" type="radio"/> 15.7 Inspect seat belt and mounting hardware | PASS |

● 15.8 Inspect seat condition, operation and mounting *PASS*

● 15.9 Replace cabin A/C filter *N/A*

OIL SAMPLING

● 16.1 Engine *PASS*

PM POST SERVICE INSPECTION CHECKS

● 17.1 All inspections have been completed and rectified as required *PASS*

● 17.2 All safety related defects have been repaired or reported *PASS*

● 17.3 All defects have been noted and reported *PASS*

● 17.4 All fluids are at correct level and drain plugs tight *PASS*

● 17.5 All oil samples have visually been inspected and any notable signs of contamination have been reported *PASS*

● 17.6 All replaced filters have been cut and inspected and photos added to CAT Inspect and reported to supervisor *PASS*

● 17.7 Machine has been recommissioned and ready for operation *PASS*

● 17.8 PM service notification marked off in Vision Link *PASS*

DEFECTS IDENTIFIED

● 18.1 DEFECTS IDENTIFIED *n*

OIL USED

● 19.1 Hydraulic oil *0*

● 19.2 Engine oil *6*

● 19.3 Slew oil *0*

● 19.4 Gear oil *2*

● 19.5 Coolant *0*