



Australian Hammer Supplies Hire
Unit 3/32 Williamson Road
Ingleburn
NSW 2565

KUBOTA SVL75 SKID STEER LOADER

Major Service

0 7 87 10

Inspection Number RP051280

Customer No

Serial Number

Customer Name

Make

Customer Email

Model SVL75-3C

Works Order RP051280

Equipment Family SKID STEER LOADER

Completed On 16/07/2025 10:06:09 AM

Asset ID AHS205

Inspector Collin Graham

Location AUSTRALIAN HAMMER SUPPLIES HIRE
Unit 3/32 WILLIAMSON RD
INGLEBURN
2565

PDF Generated On 16/07/2025

Machine Hours 573

Next Meter 500

Customer

General Info & Comments

General Info/Comments	carry out 500hr service
Machine Hours	573
Next Service Due Hours	750

TASK SAFETY INSTRUCTIONS

1.1 Wear Correct PPE at all times	PASS
1.2 All isolation and safe work procedures must be followed	PASS
1.3 Identify task hazards and controls utilising hierarchy or controls model	PASS
1.4 Ensure a competent operator and spotter is utilised to move mobile equipment	PASS
1.5 Ensure all mobile equipment is fundamentally stable	PASS

- | | | |
|----------------------------------|---|------|
| ☒ | 1.6 Ensure three points of contact is maintained during access and egress | PASS |
| ☒ | 1.7 Ensure acceptable housekeeping standards are maintained at all times | PASS |

MACHINE GENERAL RUNNINGCHECKS

- | | | |
|----------------------------------|---|------|
| ☒ | 2.1 Check all work lights, beacon & reverse alarmfor operation | PASS |
| ☒ | 2.2 Test all dash warning lights, gauges and audible alarms for correct operation | PASS |
| ☒ | 2.3 Check idle timer for correct shut down operation | PASS |
| ☒ | 2.4 Check operation of all three emergency stop buttons | PASS |
| ☒ | 2.5 Check operation of horn | PASS |
| ☒ | 2.6 Check operation of reverse camera | PASS |
| ☒ | 2.7 Check alternator charge voltage - ACTUAL_____V | PASS |
| ☐ | 2.8 Check operation of auto grease systemby manually activating timer | N/A |
| ☐ | 2.9 Check fire systemcontrol panel for 'Normal' | N/A |

PM FIRE SUPPRESSION SYSTEM

- | | | |
|----------------------------------|--|------|
| ☐ | 5.1 Ensure fire suppression bottle and components are securely mounted and in good condition | N/A |
| ☐ | 5.2 Ensure fire suppression is correctly charged | N/A |
| ☐ | 5.3 Inspect last charge date - ACTUAL _____ | N/A |
| ☒ | 5.4 Check all fire extinguishers are securely mounted and in good condition | PASS |
| ☒ | 5.5 Check all fire extinguishers are correctly charged | PASS |
| ☒ | 5.6 Inspect last charge date - ACTUAL _____ | PASS |

PM ENGINE

- | | | |
|----------------------------------|---|------|
| ☐ | 6.1 Performengine valve set | N/A |
| ☒ | 6.2 Inspect air intake systemhoses, pipes, clamps for signs of dirt ingress | PASS |

● 6.3 Inspect engine for oil or fuel leaks	PASS
● 6.4 Inspect engine components for missing clamps	PASS
● 6.5 Inspect exhaust system for signs of leaks, loose bolts or missing clamps	PASS
● 6.6 Inspect turbo for security and signs of leaks	PASS
● 6.7 Inspect condition of exhaust lagging	PASS
● 6.8 Inspect engine mounts for condition and loose hardware	PASS
● 6.9 Inspect alternator mount condition and adjustment	PASS
● 6.10 Inspect wiring condition and security	PASS
● 6.11 Inspect engine belts	PASS

PM ENGINE COOLING SYSTEM

● 7.1 Check coolant level	PASS
● 7.2 Check condition of radiator cap	PASS
● 7.3 Check condition of radiator core	PASS
● 7.4 Check cooling system for signs of leaks	PASS
● 7.5 Check hose and clamp condition	PASS
● 7.6 Inspect fan condition and operation	PASS
● 7.7 Inspect radiator and fan guard condition	PASS

PM SWING TRANSMISSION

● 8.1 Inspect swing transmission for signs of leaks	PASS
● 8.2 Inspect swing transmission oil level	PASS

PM HYDRAULIC SYSTEM

● 9.1 Check hydraulic oil level	PASS
● 9.2 Inspect hydraulic cylinders for leaks and security	PASS

● 9.3 Inspect hydraulic hoses for leaks, damage, security	PASS
● 9.4 Inspect hydraulic pump condition, leaks, security	PASS
● 9.5 Check Pilot Accumulator operation as per OEM Maintenance Procedure - Test Boom Down Functionality with engine off	PASS

PM FINAL DRIVES

● 10.1 Inspect LHS final drive mount condition for leaks and security	PASS
● 10.2 Inspect LHS oil level and mag plug condition	PASS
● 10.3 Inspect RHS final drive mount condition for leaks and security	PASS
● 10.4 Inspect RHS oil level and mag plug condition	PASS

PM UNDERCARRIAGE

● 11.1 Inspect LHS track tension	PASS
● 11.2 Inspect RHS track tension	PASS
● 11.3 Inspect tracks for loose/missing bolts	PASS
● 11.4 Inspect load and carrier rollers for signs of leaks	PASS
● 11.5 Inspect idlers for signs of leaks	PASS
● 11.6 Inspect sprocket segments condition	PASS
● 11.7 Inspect track frame for cracks, lose or missing hardware	PASS

PM FRAME AND BODY

● 12.1 Check panels for damage and security	PASS
● 12.2 Check access steps and walkway condition	PASS
● 12.3 Inspect boom condition – cracks, missing clamps, damaged pipes, excessive movement, lubrication	PASS
● 12.4 Inspect stick condition – cracks, missing clamps, damaged pipes, excessive movement, lubrication	PASS
● 12.5 Inspect quick hitch condition and operation	PASS

☐	12.6 Inspect bucket condition – cracks, wear, damage, mounts	N/A
-----------------------	--	-----

☐	12.7 Inspect GET condition and hardware	N/A
-----------------------	---	-----

PM ELECTRICAL SYSTEM

☒	13.1 Check battery condition	PASS
----------------------------------	------------------------------	------

☒	13.2 Check battery terminal condition	PASS
----------------------------------	---------------------------------------	------

☒	13.3 Check battery security	PASS
----------------------------------	-----------------------------	------

☒	13.4 Check battery box drain is clear	PASS
----------------------------------	---------------------------------------	------

☒	13.5 Check wiring condition and security	PASS
----------------------------------	--	------

PM GREASE SYSTEM

☒	14.1 Check all points for acceptable lubrication	PASS
----------------------------------	--	------

☒	14.2 Inspect grease system operation	PASS
----------------------------------	--------------------------------------	------

☒	14.3 Check grease line condition	PASS
----------------------------------	----------------------------------	------

☐	14.4 Refill grease tank	N/A
-----------------------	-------------------------	-----

☒	14.5 Lubricate bucket linkage	PASS
----------------------------------	-------------------------------	------

☒	14.6 Lubricate blade linkage	PASS
----------------------------------	------------------------------	------

☒	14.7 Lubricate boom & stick linkage	PASS
----------------------------------	-------------------------------------	------

☒	14.8 Lubricate swing bearing	PASS
----------------------------------	------------------------------	------

PM OPERATOR STATION

☒	15.1 Check all doors for correct opening and closing adjustments and operation	PASS
----------------------------------	--	------

☒	15.2 Inspect condition of door seals	PASS
----------------------------------	--------------------------------------	------

☒	15.3 Check window glass and seal condition	PASS
----------------------------------	--	------

☒	15.4 Check mirror condition and adjustments	PASS
----------------------------------	---	------

☒	15.5 Fill window washer reservoir	PASS
----------------------------------	-----------------------------------	------

●	15.6 Inspect air con vents condition	PASS
●	15.7 Inspect seat belt and mounting hardware	PASS
●	15.8 Inspect seat condition, operation and mounting	PASS
●	15.9 Replace cabin A/C filter	N/A

OIL SAMPLING

●	16.1 Engine	PASS
---	-------------	------

PM POST SERVICE INSPECTION CHECKS

●	17.1 All inspections have been completed and rectified as required	PASS
●	17.2 All safety related defects have been repaired or reported	PASS
●	17.3 All defects have been noted and reported	PASS
●	17.4 All fluids are at correct level and drain plugs tight	PASS
●	17.5 All oil samples have visually been inspected and any notable signs of contamination have been reported	PASS
●	17.6 All replaced filters have been cut and inspected and photos added to CAT Inspect and reported to supervisor	PASS
●	17.7 Machine has been recommissioned and ready for operation	PASS
●	17.8 PM service notification marked off in Vision Link	PASS

DEFECTS IDENTIFIED

●	18.1 DEFECTS IDENTIFIED	NORMAL
---	-------------------------	--------

OIL USED

●	19.1 Hydraulic oil	25
●	19.2 Enggine oil	12
●	19.3 Slew oil	3
●	19.4 Gear oil	6