



**Australian Hammer Supplies Hire**  
Unit 3/32 Williamson Road  
Ingleburn  
NSW 2565

## Minor Service

**RP053150**

Customer AUSTRALIAN HAMMER SUPPLIES HIRE Resource Etienne Llanos  
Contact

Address AUSTRALIAN HAMMER SUPPLIES HIRE Unit 3/32 WILLIAMSON RD  
INGLEBURN 2565  
Job Type Minor Service  
Reference Date 2025-09-12 11:44 - 13:54  
Job duration 2:10:00  
Driving duration 00:00:00  
Distance travelled 0 km

Notes 250HR MINOR SERVICE  
TRACKER TO BE INSTALLED

Customer/Technician

Resource notes

250hr service, no faults and damages reported in dehire

## Minor Service

**Answer**

**Notes**

**General Info/Comments** 250hr service at 357

**Machine Hours** 357.6

**Next Service Due Hours** 500

**1.1 Wear Correct PPE at all times** PASS

**1.2 All isolation and safe work procedures must be followed** PASS

**1.3 Identify task hazards and controls utilising hierarchy or controls model** PASS

**1.4 Ensure a competent operator and spotter is utilised to move mobile equipment** PASS

**1.5 Ensure all mobile equipment is fundamentally stable** PASS

**1.6 Ensure three points of contact is maintained** PASS



**Australian Hammer Supplies Hire**  
Unit 3/32 Williamson Road  
Ingleburn  
NSW 2565

during access and egress

|                                                                          |      |
|--------------------------------------------------------------------------|------|
| 1.7 Ensure acceptable housekeeping standards are maintained at all times | PASS |
|--------------------------------------------------------------------------|------|

|                                                                 |      |
|-----------------------------------------------------------------|------|
| 2.1 Check all work lights, beacon & reverse alarm for operation | PASS |
|-----------------------------------------------------------------|------|

|                                                                                   |      |
|-----------------------------------------------------------------------------------|------|
| 2.2 Test all dash warning lights, gauges and audible alarms for correct operation | PASS |
|-----------------------------------------------------------------------------------|------|

|                                                      |      |
|------------------------------------------------------|------|
| 2.3 Check idle timer for correct shut down operation | PASS |
|------------------------------------------------------|------|

|                                                         |      |
|---------------------------------------------------------|------|
| 2.4 Check operation of all three emergency stop buttons | PASS |
|---------------------------------------------------------|------|

|                             |      |
|-----------------------------|------|
| 2.5 Check operation of horn | PASS |
|-----------------------------|------|

|                                       |      |
|---------------------------------------|------|
| 2.6 Check operation of reverse camera | PASS |
|---------------------------------------|------|

|                                     |      |
|-------------------------------------|------|
| 2.7 Check alternator charge voltage | PASS |
|-------------------------------------|------|

|                                                                        |     |
|------------------------------------------------------------------------|-----|
| 2.8 Check operation of auto grease system by manually activating timer | N/A |
|------------------------------------------------------------------------|-----|

|                                                  |      |
|--------------------------------------------------|------|
| 2.9 Check fire system control panel for 'Normal' | PASS |
|--------------------------------------------------|------|

|                                                                                              |     |
|----------------------------------------------------------------------------------------------|-----|
| 5.1 Ensure fire suppression bottle and components are securely mounted and in good condition | N/A |
|----------------------------------------------------------------------------------------------|-----|

|                                                  |     |
|--------------------------------------------------|-----|
| 5.2 Ensure fire suppression is correctly charged | N/A |
|--------------------------------------------------|-----|

|                              |                                  |
|------------------------------|----------------------------------|
| 5.3 Inspect last charge date | DATE:2025-09-12T00:00:00.0000000 |
|------------------------------|----------------------------------|

|                                                                             |      |
|-----------------------------------------------------------------------------|------|
| 5.4 Check all fire extinguishers are securely mounted and in good condition | PASS |
|-----------------------------------------------------------------------------|------|

|                                                        |      |
|--------------------------------------------------------|------|
| 5.5 Check all fire extinguishers are correctly charged | PASS |
|--------------------------------------------------------|------|

|                              |                                  |
|------------------------------|----------------------------------|
| 5.6 Inspect last charge date | DATE:2025-09-12T00:00:00.0000000 |
|------------------------------|----------------------------------|

|                              |      |
|------------------------------|------|
| 6.1 Perform engine valve set | PASS |
|------------------------------|------|

|                                                                              |      |
|------------------------------------------------------------------------------|------|
| 6.2 Inspect air intake system hoses, pipes, clamps for signs of dirt ingress | PASS |
|------------------------------------------------------------------------------|------|

|                                          |      |
|------------------------------------------|------|
| 6.3 Inspect engine for oil or fuel leaks | PASS |
|------------------------------------------|------|

|                                                  |      |
|--------------------------------------------------|------|
| 6.4 Inspect engine components for missing clamps | PASS |
|--------------------------------------------------|------|

|                                                                              |      |
|------------------------------------------------------------------------------|------|
| 6.5 Inspect exhaust system for signs of leaks, loose bolts or missing clamps | PASS |
|------------------------------------------------------------------------------|------|

|                                                   |      |
|---------------------------------------------------|------|
| 6.6 Inspect turbo for security and signs of leaks | PASS |
|---------------------------------------------------|------|

|                                          |      |
|------------------------------------------|------|
| 6.7 Inspect condition of exhaust lagging | PASS |
|------------------------------------------|------|

|                                                            |      |
|------------------------------------------------------------|------|
| 6.8 Inspect engine mounts for condition and loose hardware | PASS |
|------------------------------------------------------------|------|

|                                                       |      |
|-------------------------------------------------------|------|
| 6.9 Inspect alternator mount condition and adjustment | PASS |
|-------------------------------------------------------|------|

|                                            |      |
|--------------------------------------------|------|
| 6.10 Inspect wiring condition and security | PASS |
|--------------------------------------------|------|

|                           |      |
|---------------------------|------|
| 6.11 Inspect engine belts | PASS |
|---------------------------|------|

|                                                                                                                       |      |
|-----------------------------------------------------------------------------------------------------------------------|------|
| 7.1 Check coolant level                                                                                               | PASS |
| 7.2 Check condition of radiator cap                                                                                   | PASS |
| 7.3 Check condition of radiator core                                                                                  | PASS |
| 7.4 Check cooling system for signs of leaks                                                                           | PASS |
| 7.5 Check hose and clamp condition                                                                                    | PASS |
| 7.6 Inspect fan condition and operation                                                                               | PASS |
| 7.7 Inspect radiator and fan guard condition                                                                          | PASS |
| 8.1 Inspect swing transmission for signs of leaks                                                                     | PASS |
| 8.2 Inspect swing transmission oil level                                                                              | PASS |
| 9.1 Check hydraulic oil level                                                                                         | PASS |
| 9.2 Inspect hydraulic cylinders for leaks and security                                                                | PASS |
| 9.3 Inspect hydraulic hoses for leaks, damage, security                                                               | PASS |
| 9.4 Inspect hydraulic pump condition, leaks, security                                                                 | PASS |
| 9.5 Check Pilot Accumulator operation as per OEM Maintenance Procedure - Test Boom Down Functionality with engine off | PASS |
| 10.1 Inspect LHS final drive mount condition for leaks and security                                                   | PASS |
| 10.2 Inspect LHS oil level and mag plug condition                                                                     | PASS |
| 10.3 Inspect RHS final drive mount condition for leaks and security                                                   | PASS |
| 10.4 Inspect RHS oil level and mag plug condition                                                                     | PASS |
| 11.1 Inspect LHS track tension                                                                                        | PASS |
| 11.2 Inspect RHS track tension                                                                                        | PASS |
| 11.3 Inspect tracks for loose/missing bolts                                                                           | PASS |
| 11.4 Inspect load and carrier rollers for signs of leaks                                                              | PASS |
| 11.5 Inspect idlers for signs of leaks                                                                                | PASS |
| 11.6 Inspect sprocket segments condition                                                                              | PASS |
| 11.7 Inspect track frame for cracks, loose or missing hardware                                                        | PASS |
| 12.1 Check panels for damage and security                                                                             | PASS |
| 12.2 Check access steps and walkway condition                                                                         | PASS |
| 12.3 Inspect boom condition – cracks, missing clamps, damaged pipes, excessive movement, lubrication                  | PASS |

|                                                                                                              |      |
|--------------------------------------------------------------------------------------------------------------|------|
| <b>12.4 Inspect stick condition – cracks, missing clamps, damaged pipes, excessive movement, lubrication</b> | PASS |
| <b>12.5 Inspect quick hitch condition and operation</b>                                                      | PASS |
| <b>12.6 Inspect bucket condition – cracks, wear, damage, mounts</b>                                          | PASS |
| <b>12.7 Inspect GET condition and hardware</b>                                                               | PASS |
| <b>13.1 Check battery condition</b>                                                                          | PASS |
| <b>13.2 Check battery terminal condition</b>                                                                 | PASS |
| <b>13.3 Check battery security</b>                                                                           | PASS |
| <b>13.4 Check battery box drain is clear</b>                                                                 | PASS |
| <b>13.5 Check wiring condition and security</b>                                                              | PASS |
| <b>14.1 Check all points for acceptable lubrication</b>                                                      | PASS |
| <b>14.2 Inspect grease system operation</b>                                                                  | PASS |
| <b>14.3 Check grease line condition</b>                                                                      | PASS |
| <b>14.4 Refill grease tank</b>                                                                               | N/A  |
| <b>14.5 Lubricate bucket linkage</b>                                                                         | PASS |
| <b>14.6 Lubricate blade linkage</b>                                                                          | PASS |
| <b>14.7 Lubricate boom &amp; stick linkage</b>                                                               | PASS |
| <b>14.8 Lubricate swing bearing</b>                                                                          | PASS |
| <b>15.1 Check all doors for correct opening and closing adjustments and operation</b>                        | PASS |
| <b>15.2 Inspect condition of door seals</b>                                                                  | PASS |
| <b>15.3 Check window glass and seal condition</b>                                                            | PASS |
| <b>15.4 Check mirror condition and adjustments</b>                                                           | PASS |
| <b>15.5 Fill window washer reservoir</b>                                                                     | PASS |
| <b>15.6 Inspect air con vents condition</b>                                                                  | PASS |
| <b>15.7 Inspect seat belt and mounting hardware</b>                                                          | PASS |
| <b>15.8 Inspect seat condition, operation and mounting</b>                                                   | PASS |
| <b>15.9 Replace cabin A/C filter</b>                                                                         | PASS |
| <b>16.1 Engine</b>                                                                                           | PASS |
| <b>17.1 All inspections have been completed and rectified as required</b>                                    | PASS |
| <b>17.2 All safety related defects have been repaired or reported</b>                                        | PASS |
| <b>17.3 All defects have been noted and reported</b>                                                         | PASS |



**Australian Hammer Supplies Hire**  
Unit 3/32 Williamson Road  
Ingleburn  
NSW 2565

---

|                                                            |      |
|------------------------------------------------------------|------|
| 17.4 All fluids are at correct level and drain plugs tight | PASS |
|------------------------------------------------------------|------|

---

|                                                                                                             |      |
|-------------------------------------------------------------------------------------------------------------|------|
| 17.5 All oil samples have visually been inspected and any notable signs of contamination have been reported | PASS |
|-------------------------------------------------------------------------------------------------------------|------|

---

|                                                                                                                  |     |
|------------------------------------------------------------------------------------------------------------------|-----|
| 17.6 All replaced filters have been cut and inspected and photos added to CAT Inspect and reported to supervisor | N/A |
|------------------------------------------------------------------------------------------------------------------|-----|

---

|                                                              |      |
|--------------------------------------------------------------|------|
| 17.7 Machine has been recommissioned and ready for operation | PASS |
|--------------------------------------------------------------|------|

---

|                                                        |     |
|--------------------------------------------------------|-----|
| 17.8 PM service notification marked off in Vision Link | N/A |
|--------------------------------------------------------|-----|

---

|                         |     |
|-------------------------|-----|
| 18.1 DEFECTS IDENTIFIED | n/a |
|-------------------------|-----|

---

|                    |   |
|--------------------|---|
| 19.1 Hydraulic oil | 5 |
|--------------------|---|

---

|                 |    |
|-----------------|----|
| 19.2 Engine oil | 12 |
|-----------------|----|

---

|               |   |
|---------------|---|
| 19.3 Slew oil | 0 |
|---------------|---|

---

|               |   |
|---------------|---|
| 19.4 Gear oil | 0 |
|---------------|---|

---

|              |   |
|--------------|---|
| 19.5 Coolant | 0 |
|--------------|---|

---



**Australian Hammer Supplies Hire**  
Unit 3/32 Williamson Road  
Ingleburn  
NSW 2565

#### General Info/Comments



#### General Info/Comments



#### General Info/Comments

