

## Transport

### **WARNING Falling hydraulic breaker**


If the hydraulic breaker is tipping over and falling, it may cause serious injury.

► Place the hydraulic breaker in a safe position where it cannot fall over and cause damage.

### **Lifting the hydraulic breaker**

Carefully check that the carrier is stable enough when transporting, performing maintenance, or other kinds of work with the hydraulic breaker.

The hydraulic breaker is delivered in a box. To lift the hydraulic breaker in a safe way, fit the lifting strap in the manner shown in the illustration below.



### **Transport using a forklift**

When using a forklift. Place the hydraulic breaker at a pallet. Use wedges and strapping to secure it. Slowly lift and transport the hydraulic breaker to its intended destination.

### **Transport using a lorry**

Put the hydraulic breaker on an anti-slip mat at the lorry. Secure the machine to the loading surface with straps.

Observe all the applicable national and regional regulations on securing loads.