


Safe Operating Procedures

Make: Atlas Copco
Model: HB2500
Type: Percussion Hammer - Attachment
Plant Number: 22H
Serial Number: 2682008



Recommended PPE - Subject to Company & Site Policy



SOP Percussion Hammer - Attachment

GENERAL & START UP

- Read & understand manufacturer's operational manual
- Complete pre-operational checklist (never use faulty or defective machinery)
- All operators must be free from direct and after effects of alcohol and drugs
- Ensure that an appropriate, charged fire extinguisher is available in the carrier unit
- Ensure carrier unit and percussion hammer are compatible
- Ensure percussion hammer is properly attached to carrier unit prior to operation
- Know your carrier unit, its attachments and how they work
- Ensure work area is clear of all bystanders and hazards prior to starting engine and operating machine
- Once engine is started confirm control pattern and machine function
- Use care in close proximity to operator work area, do not contact carrier machine with percussion hammer
- Never touch any part of the percussion hammer or hydraulic hoses after operation due to excessive heat

COUPLING

ALWAYS:

- wear gloves when handling hydraulic lines
- ensure all hydraulic lines are connected correctly and free from leaks and damage (never use your hands to check for leaks, use wood or cardboard)
- ensure lynch pins and clips are correctly attached prior to operation
- ensure that a mechanical safety system such as a safety pin and lynch pin is present and engaged at all times whilst this item of plant is in operation (Semi-automatic quick hitches only)

NEVER:

- use fingers to line up holes on linkage arms
- attempt to connect hydraulic couplings with carrier unit running

UNCOUPLING

ALWAYS:

- lower hammer so that it is safely and sturdily supported on level ground before disconnection
- ensure all couplings, hydraulic lines and electrical fittings are disconnected prior to uncoupling
- ensure hammer is stored in a manner to reduce likelihood of hazards, store hammer on a purpose built stand or lay flat on the ground positioned so it can be readily re-attached to machine without the need for manual movement or repositioning

NEVER:

- attempt to disconnect hydraulic couplings with carrier unit running
- force hammer into the ground and uncouple

OPERATION

ALWAYS:

- ensure work area is clear of all bystanders and hazards prior to starting engine and operating hammer
- close the front screen / splinter guard on the operator cabin to avoid injury from debris

NEVER:

- start the hammer until in the correct working position and contact pressure is applied
- lever the material with the hammer
- operate the percussion hammer with hydraulic cylinders fully extended or retracted as this can cause serious damage to carrier unit

Know the location of any utility services in the construction area, damage to gas or power lines could lead to a electrocution, fire or explosion
Refer to power line approach distance label re safety around power lines
Never operate the hammer in an environment where flammable gases could be present
Always hand excavate in close proximity to services taking material to be excavated into consideration
Always provide sufficient ventilation when working in buildings or confined areas

Safe Operating Procedures

~~Always provide sufficient ventilation when working in buildings or confined areas~~

MAINTENANCE

Maintain percussion hammer with care, inspect hoses periodically and if damaged, have repaired by authorized service facility (never use your hands to check for leaks, use wood or cardboard)
Stop engine if the percussion hammer starts to vibrate abnormally
Follow OEM instructions for lubrication and changing accessories

Operator Signature:

Name: _____ Date: _____ Signature: _____