


Safe Operating Procedures

Make: Nuosen
Model: NS155
Type: Percussion Hammer - Attachment
Plant Number: 23S



Recommended PPE - Subject to Company & Site Policy



SOP Percussion Hammer - Attachment

GENERAL & START UP

- Read & understand manufacturer's operational manual
- Complete pre-operational checklist (never use faulty or defective machinery)
- All operators must be free from direct and after effects of alcohol and drugs
- Ensure that an appropriate, charged fire extinguisher is available in the carrier unit
- Ensure carrier unit and percussion hammer are compatible
- Ensure percussion hammer is properly attached to carrier unit prior to operation
- Know your carrier unit, its attachments and how they work
- Ensure work area is clear of all bystanders and hazards prior to starting engine and operating machine
- Once engine is started confirm control pattern and machine function
- Use care in close proximity to operator work area, do not contact carrier machine with percussion hammer
- Never touch any part of the percussion hammer or hydraulic hoses after operation due to excessive heat

COUPLING

ALWAYS:

- wear gloves when handling hydraulic lines
- ensure all hydraulic lines are connected correctly and free from leaks and damage (never use your hands to check for leaks, use wood or cardboard)
- ensure lynch pins and clips are correctly attached prior to operation
- ensure that a mechanical safety system such as a safety pin and lynch pin is present and engaged at all times whilst this item of plant is in operation (Semi-automatic quick hitches only)

NEVER:

- use fingers to line up holes on linkage arms
- attempt to connect hydraulic couplings with carrier unit running

UNCOUPLING

ALWAYS:

- lower hammer so that it is safely and sturdily supported on level ground before disconnection
- ensure all couplings, hydraulic lines and electrical fittings are disconnected prior to uncoupling
- ensure hammer is stored in a manner to reduce likelihood of hazards, store hammer on a purpose built stand or lay flat on the ground positioned so it can be readily re-attached to machine without the need for manual movement or repositioning

NEVER:

- attempt to disconnect hydraulic couplings with carrier unit running
- force hammer into the ground and uncouple

OPERATION

ALWAYS:

- ensure work area is clear of all bystanders and hazards prior to starting engine and operating hammer
- close the front screen / splinter guard on the operator cabin to avoid injury from debris

