**Australian Hammer Supplies Hire**
Unit 3/32 Williamson Road
Ingleburn
NSW 2565

# KUBOTA U55-4 EXCAVATOR

## Major Service

0 13 87 8

| | | | |
|---|---|---|---|
| Inspection Number | RP062977 | Customer No | 200000 |
| Serial Number | 26415 | Customer Name | AUSTRALIAN HAMMER SUPPLIES HIRE |
| Make | KUBOTA | Customer Email | |
| Model | U55-4 | Works Order | RP062977 |
| Equipment Family | 4.1-6T HYDRAULIC EXCAVATOR | Completed On | 12/11/2026 9:08:47 AM |
| Asset ID | AHSH185 | Inspector | Jake Raffen |
| Location | AUSTRAILAN HAMMER SUPPLIES HIRE<br>Unit 3/32 WILLIAMSON RD<br>INGLEBURN<br>2565 | PDF Generated On | 12/11/2026 |
| | | Machine Hours | 2028.6 |
| | | Next Meter | 2250 |

Customer



## General Info & Comments


**Australian Hammer Supplies Hire**
Unit 3/32 Williamson Road
Ingleburn
NSW 2565

**General Info/Comments** *2000 hour service*









## TASK SAFETY INSTRUCTIONS

| | |
|---|---|
| **1.1 Wear Correct PPE at all times** | *NORMAL* |
| **1.2 All isolation and safe work procedures must be followed** | *NORMAL* |
| **1.3 Identify task hazards and controls utilising hierarchy or controls model** | *NORMAL* |
| **1.4 Ensure a competent operator and spotter is utilised to move mobile equipment** | *NORMAL* |
| **1.5 Ensure all mobile equipment is fundamentally stable** | *NORMAL* |
| **1.6 Ensure three points of contact is maintained during access and egress** | *NORMAL* |
| **1.7 Ensure acceptable housekeeping standards are maintained at all times** | *NORMAL* |

## MACHINE GENERAL RUNNINGCHECKS

| | |
|---|---|
| **2.1 Check all work lights, beacon & reverse alarmfor operation** | *PASS* |
| **2.2 Test all dash warning lights, gauges and audible alarms for correct operation** | *PASS* |
| **2.3 Check idle timer for correct shut down operation** | *N/A* |
| **2.4 Check operation of all three emergency stop buttons** | *PASS* |
| **2.5 Check operation of horn** | *PASS* |
| **2.6 Check operation of reverse camera** | *PASS* |
| **2.7 Check alternator charge voltage** | *PASS* |
| **2.8 Check operation of auto grease systemby manually activating timer** | *PASS* |
| **2.9 Check fire systemcontrol panel for 'Normal'** | *N/A* |

## PM FIRE SUPPRESSION SYSTEM

| | |
|---|---|
| **5.1 Ensure fire suppression bottle and components are securely mounted and in good condition** | *N/A* |
| **5.2 Ensure fire suppression is correctly charged** | *N/A* |
| **5.3 Inspect last charge date** | *DATE:2026-11-10 T00:00:00.0000000* |
| **5.4 Check all fire extinguishers are securely mounted and in good condition** | *PASS* |
| **5.5 Check all fire extinguishers are correctly charged** | *PASS* |
| **5.6 Inspect last charge date** | *DATE:2026-11-10 T00:00:00.0000000* |

## PM ENGINE

| | |
|---|---|
| **6.1 Performengine valve set** | *N/A* |
| **6.2 Inspect air intake systemhoses, pipes, clamps for signs of dirt ingress** | *PASS* |
| **6.3 Inspect engine for oil or fuel leaks** | *PASS* |
| **6.4 Inspect engine components for missing clamps** | *PASS* |

| | |
|---|---|
| **6.5 Inspect exhaust systemfor signs of leaks, loose bolts or missing clamps** | *PASS* |
| **6.6 Inspect turbo for security and signs of leaks** | *PASS* |
| **6.7 Inspect condition of exhaust lagging** | *PASS* |
| **6.8 Inspect engine mounts for condition and loose hardware** | *PASS* |
| **6.9 Inspect alternator mount condition and adjustment** | *PASS* |
| **6.10 Inspect wiring condition and security** | *PASS* |
| **6.11 Inspect engine belts** | *PASS* |

## PM ENGINE COOLINGSYSTEM

| | |
|---|---|
| **7.1 Check coolant level** | *PASS* |
| **7.2 Check condition of radiator cap** | *PASS* |
| **7.3 Check condition of radiator core** | *PASS* |
| **7.4 Check cooling systemfor signs of leaks** | *PASS* |
| **7.5 Check hose and clamp condition** | *PASS* |
| **7.6 Inspect fan condition and operation** | *PASS* |
| **7.7 Inspect radiator and fan guard condition** | *PASS* |

## PM SWINGTRANSMISSION

| | |
|---|---|
| **8.1 Inspect swing transmission for signs of leaks** | *PASS* |
| **8.2 Inspect swing transmission oil level** | *PASS* |

## PM HYDRAULIC SYSTEM

| | |
|---|---|
| **9.1 Check hydraulic oil level** | *PASS* |
| **9.2 Inspect hydraulic cylinders for leaks and security** | *PASS* |
| **9.3 Inspect hydraulic hoses for leaks, damage, security** | *PASS* |
| **9.4 Inspect hydraulic pump condition, leaks, security** | *PASS* |

| | |
|---|---|
| **9.5 Check Pilot Accumulator operation as per OEM Maintenance Procedure - Test Boom Down Functionality with engine off** | *PASS* |

## PM FINAL DRIVES

| | |
|---|---|
| **10.1 Inspect LHS final drive mount condition for leaks and security** | *PASS* |
| **10.2 Inspect LHS oil level and mag plug condition** | *PASS* |
| **10.3 Inspect RHS final drive mount condition for leaks and security** | *PASS* |
| **10.4 Inspect RHS oil level and mag plug condition** | *PASS* |

## PM UNDERCARRIAGE

| | |
|---|---|
| **11.1 Inspect LHS track tension** | *PASS* |
| **11.2 Inspect RHS track tension** | *PASS* |
| **11.3 Inspect tracks for loose/missing bolts** | *PASS* |
| **11.4 Inspect load and carrier rollers for signs of leaks** | *PASS* |
| **11.5 Inspect idlers for signs of leaks** | *PASS* |
| **11.6 Inspect sprocket segments condition** | *PASS* |
| **11.7 Inspect track frame for cracks, lose or missing hardware** | *PASS* |

## PM FRAME AND BODY

| | |
|---|---|
| **12.1 Check panels for damage and security** | *PASS* |
| **12.2 Check access steps and walkway condition** | *PASS* |
| **12.3 Inspect boom condition – cracks, missing clamps, damaged pipes, excessive movement, lubrication** | *PASS* |
| **12.4 Inspect stick condition – cracks, missing clamps, damaged pipes, excessive movement, lubrication** | *PASS* |
| **12.5 Inspect quick hitch condition and operation** | *PASS* |
| **12.6 Inspect bucket condition – cracks, wear, damage, mounts** | *PASS* |
| **12.7 Inspect GET condition and hardware** | *PASS* |

**Australian Hammer Supplies Hire**
Unit 3/32 Williamson Road
Ingleburn
NSW 2565

## PM ELECTRICAL SYSTEM

| | |
|---|---|
| **13.1 Check battery condition** | *PASS* |
| **13.2 Check battery terminal condition** | *PASS* |
| **13.3 Check battery security** | *PASS* |
| **13.4 Check battery box drain is clear** | *PASS* |
| **13.5 Check wiring condition and security** | *PASS* |

## PM GREASE SYSTEM

| | |
|---|---|
| **14.1 Check all points for acceptable lubrication** | *PASS* |
| **14.2 Inspect grease systemoperation** | *PASS* |
| **14.3 Check grease line condition** | *PASS* |
| **14.4 Refill grease tank** | *N/A* |
| **14.5 Lubricate bucket linkage** | *PASS* |
| **14.6 Lubricate blade linkage** | *PASS* |
| **14.7 Lubricate boom& stick linkage** | *PASS* |
| **14.8 Lubricate swing bearing** | *PASS* |

## PM OPERATOR STATION

| | |
|---|---|
| **15.1 Check all doors for correct opening and closing adjustments and operation** | *PASS* |
| **15.2 Inspect condition of door seals** | *PASS* |
| **15.3 Check window glass and seal condition** | *PASS* |
| **15.4 Check mirror condition and adjustments** | *PASS* |
| **15.5 Fill window washer reservoir** | *PASS* |
| **15.6 Inspect air con vents condition** | *PASS* |
| **15.7 Inspect seat belt and mounting hardware** | *PASS* |

| | |
|---|---|
| **15.8 Inspect seat condition, operation and mounting** | *PASS* |
| **15.9 Replace cabin A/C filter** | *PASS* |

## OIL SAMPLING

| | |
|---|---|
| **16.1 Engine** | *NORMAL* |

## PM POST SERVICE INSPECTION CHECKS

| | |
|---|---|
| **17.1 All inspections have been completed and rectified as required** | *NORMAL* |
| **17.2 All safety related defects have been repaired or reported** | *NORMAL* |
| **17.3 All defects have been noted and reported** | *NORMAL* |
| **17.4 All fluids are at correct level and drain plugs tight** | *NORMAL* |
| **17.5 All oil samples have visually been inspected and any notable signs of contamination have been reported** | *NORMAL* |
| **17.6 All replaced filters have been cut and inspected and photos added to CAT Inspect and reported to supervisor** | *N/A* |
| **17.7 Machine has been recommissioned and ready for operation** | *NORMAL* |
| **17.8 PM service notification marked off in Vision Link** | *N/A* |

## DEFECTS IDENTIFIED

| | |
|---|---|
| **18.1 DEFECTS IDENTIFIED** | *normal* |

## OIL USED

| | |
|---|---|
| **19.1 Hydraulic oil** | *0* |
| **19.2 Engine oil** | *11* |
| **19.3 Slew oil** | *0* |
| **19.4 Gear oil** | *3* |
| **19.5 Coolant** | *0* |

**Australian Hammer Supplies Hire**
Unit 3/32 Williamson Road
Ingleburn
NSW 2565

- **Site photo**
- **Site photo**
- **Site photo**
- **Site photo**