

Minor Service RP051739

Customer AUSTRALIAN HAMMER SUPPLIES HIRE Resource Jake Raffen

Contact

Address AUSTRAILAN HAMMER SUPPLIES HIRE

Unit 3/32 WILLIAMSON RD

INGLEBURN

2565

Job Type Minor Service

Reference

Date 2025-07-29 12:06 - 12:13

Job duration 2:0:00
Driving duration 00:00:00
Distance travelled 0 km

Notes AHSH77 - 9250HR MINOR SERVICE

Site address - 113 Smallwood Rd Glenorie Site contact - Charbel 0402 932 209

Customer/Technician



Resource notes

As per dehire work order defects - Quick hitch leak out of relief valve, Both dog bones bent, R/h dog bone missing pin locking tabs, Hlink pin locking tounge been cut to shape, Aux lines missing caps, L/H tracks loose and both have excessive amount of dirt build up on frames, machine has not been regularly greased - bearing failure noise coming from stick pivot and cylinder rod bearings. Operator Cab needs deep clean as cab smells of cigarette smoke. Missing handrail behind snake pit and above control valve and missing hardware.

| Minor Service | | | |
|--|---------------|-------|--|
| | Answer | Notes | |
| General Info/Comments | 250hr service | | |
| Machine Hours | 9164 | | |
| Next Service Due Hours | 9500 | | |
| 1.1 Wear Correct PPE at all times | NORMAL | | |
| 1.2 All isolation and safe work procedures must be followed | NORMAL | | |
| 1.3 Identify task hazards and controls utilising hierarchy or controls model | NORMAL | | |
| 1.4 Ensure a competent operator and spotter is | NORMAL | | |

1.4 Ensure a competent operator and spotter is utilised to move mobile equipment

NORMAL



| 1.5 Ensure all mobile equipment is fundamentally stable | NORMAL |
|--|--------|
| 1.6 Ensure three points of contact is maintained during access and egress | NORMAL |
| 1.7 Ensure acceptable housekeeping standards are maintained at all times | NORMAL |
| 2.1 Check all work lights, beacon & reverse alarmfor operation | PASS |
| 2.2 Test all dash warning lights, gauges and audible alarms for correct operation | PASS |
| 2.3 Check idle timer for correct shut down operation | N/A |
| 2.4 Check operation of all three emergency stop buttons | PASS |
| 2.5 Check operation of horn | PASS |
| 2.6 Check operation of reverse camera | PASS |
| 2.7 Check alternator charge voltage - ACTUALV | PASS |
| 2.8 Check operation of auto grease systemby manually activating timer | PASS |
| 2.9 Check fire systemcontrol panel for 'Normal' | N/A |
| 5.1 Ensure fire suppression bottle and components are securely mounted and in good condition | N/A |
| 5.2 Ensure fire suppression is correctly charged | N/A |
| 5.3 Inspect last charge date - ACTUAL | N/A |
| 5.4 Check all fire extinguishers are securely mounted and in good condition | PASS |
| 5.5 Check all fire extinguishers are correctly charged | PASS |
| 5.6 Inspect last charge date - ACTUAL | PASS |
| 6.1 Performengine valve set | N/A |
| 6.2 Inspect air intake systemhoses, pipes, clamps for signs of dirt ingress | PASS |
| 6.3 Inspect engine for oil or fuel leaks | PASS |
| 6.4 Inspect engine components for missing clamps | PASS |
| 6.5 Inspect exhaust systemfor signs of leaks, loose bolts or missing clamps | PASS |
| 6.6 Inspect turbo for security and signs of leaks | PASS |
| 6.7 Inspect condition of exhaust lagging | N/A |
| 6.8 Inspect engine mounts for condition and loose | PASS |



11.7 Inspect track frame for cracks, lose or missing

hardware

Australian Hammer Supplies Hire Unit 3/32 Williamson Road Ingleburn NSW 2565

| hardware | |
|---|--------|
| 6.9 Inspect alternator mount condition and adjustment | PASS |
| 6.10 Inspect wiring condition and security | PASS |
| 6.11 Inspect engine belts | PASS |
| 7.1 Check coolant level | PASS |
| 7.2 Check condition of radiator cap | PASS |
| 7.3 Check condition of radiator core | PASS |
| 7.4 Check cooling systemfor signs of leaks | PASS |
| 7.5 Check hose and clamp condition | PASS |
| 7.6 Inspect fan condition and operation | PASS |
| 7.7 Inspect radiator and fan guard condition | PASS |
| 8.1 Inspect swing transmission for signs of leaks | PASS |
| 8.2 Inspect swing transmission oil level | PASS |
| 9.1 Check hydraulic oil level | PASS |
| 9.2 Inspect hydraulic cylinders for leaks and security | PASS |
| 9.3 Inspect hydraulic hoses for leaks, damage, security | PASS |
| 9.4 Inspect hydraulic pump condition, leaks, security | PASS |
| 9.5 Check Pilot Accumulator operation as per OEM Maintenance Procedure - Test Boom Down Functionality with engine off | PASS |
| 10.1 Inspect LHS final drive mount condition for leaks and security | PASS |
| 10.2 Inspect LHS oil level and mag plug condition | PASS |
| 10.3 Inspect RHS final drive mount condition for leaks and security | PASS |
| 10.4 Inspect RHS oil level and mag plug condition | PASS |
| 11.1 Inspect LHS track tension | NORMAL |
| 11.2 Inspect RHS track tension | NORMAL |
| 11.3 Inspect tracks for loose/missing bolts | NORMAL |
| 11.4 Inspect load and carrier rollers for signs of leaks | NORMAL |
| 11.5 Inspect idlers for signs of leaks | NORMAL |
| 11.6 Inspect sprocket segments condition | NORMAL |
| 11.7 Inspect track frame for cracks, lose or missing | NORMAL |

NORMAL



| 12.1 Check panels for damage and security | PASS |
|--|--|
| 12.2 Check access steps and walkway condition | PASS |
| 12.3 Inspect boom condition – cracks, missing clamps, damaged pipes, excessive movement, lubrication | PASS |
| 12.4 Inspect stick condition – cracks, missing clamps, damaged pipes, excessive movement, lubrication | PASS |
| 12.5 Inspect quick hitch condition and operation | FAIL |
| 12.6 Inspect bucket condition – cracks, wear, damage, mounts | N/A |
| 12.7 Inspect GET condition and hardware | N/A |
| 13.1 Check battery condition | PASS |
| 13.2 Check battery terminal condition | PASS |
| 13.3 Check battery security | PASS |
| 13.4 Check battery box drain is clear | PASS |
| 13.5 Check wiring condition and security | PASS |
| 14.1 Check all points for acceptable lubrication | PASS |
| 14.2 Inspect grease systemoperation | PASS |
| THE Mopost groups systems por ation | .,,,,,, |
| 14.3 Check grease line condition | PASS |
| | |
| 14.3 Check grease line condition | PASS |
| 14.3 Check grease line condition 14.4 Refill grease tank | PASS NORMAL |
| 14.3 Check grease line condition 14.4 Refill grease tank 14.5 Lubricate bucket linkage | PASS NORMAL PASS |
| 14.3 Check grease line condition 14.4 Refill grease tank 14.5 Lubricate bucket linkage 14.6 Lubricate blade linkage | PASS NORMAL PASS PASS |
| 14.3 Check grease line condition 14.4 Refill grease tank 14.5 Lubricate bucket linkage 14.6 Lubricate blade linkage 14.7 Lubricate boom& stick linkage | PASS NORMAL PASS PASS FAIL |
| 14.3 Check grease line condition 14.4 Refill grease tank 14.5 Lubricate bucket linkage 14.6 Lubricate blade linkage 14.7 Lubricate boom& stick linkage 14.8 Lubricate swing bearing 15.1 Check all doors for correct opening and | PASS NORMAL PASS PASS FAIL PASS |
| 14.3 Check grease line condition 14.4 Refill grease tank 14.5 Lubricate bucket linkage 14.6 Lubricate blade linkage 14.7 Lubricate boom& stick linkage 14.8 Lubricate swing bearing 15.1 Check all doors for correct opening and closing adjustments and operation | PASS NORMAL PASS PASS FAIL PASS PASS |
| 14.3 Check grease line condition 14.4 Refill grease tank 14.5 Lubricate bucket linkage 14.6 Lubricate blade linkage 14.7 Lubricate boom& stick linkage 14.8 Lubricate swing bearing 15.1 Check all doors for correct opening and closing adjustments and operation 15.2 Inspect condition of door seals | PASS NORMAL PASS PASS FAIL PASS PASS PASS |
| 14.3 Check grease line condition 14.4 Refill grease tank 14.5 Lubricate bucket linkage 14.6 Lubricate blade linkage 14.7 Lubricate boom& stick linkage 14.8 Lubricate swing bearing 15.1 Check all doors for correct opening and closing adjustments and operation 15.2 Inspect condition of door seals 15.3 Check window glass and seal condition | PASS NORMAL PASS PASS FAIL PASS PASS PASS PASS |
| 14.3 Check grease line condition 14.4 Refill grease tank 14.5 Lubricate bucket linkage 14.6 Lubricate blade linkage 14.7 Lubricate boom& stick linkage 14.8 Lubricate swing bearing 15.1 Check all doors for correct opening and closing adjustments and operation 15.2 Inspect condition of door seals 15.3 Check window glass and seal condition 15.4 Check mirror condition and adjustments | PASS NORMAL PASS PASS FAIL PASS PASS PASS PASS PASS |
| 14.3 Check grease line condition 14.4 Refill grease tank 14.5 Lubricate bucket linkage 14.6 Lubricate blade linkage 14.7 Lubricate boom& stick linkage 14.8 Lubricate swing bearing 15.1 Check all doors for correct opening and closing adjustments and operation 15.2 Inspect condition of door seals 15.3 Check window glass and seal condition 15.4 Check mirror condition and adjustments 15.5 Fill window washer reservoir | PASS NORMAL PASS PASS FAIL PASS PASS PASS PASS PASS PASS N/A |
| 14.3 Check grease line condition 14.4 Refill grease tank 14.5 Lubricate bucket linkage 14.6 Lubricate blade linkage 14.7 Lubricate boom& stick linkage 14.8 Lubricate swing bearing 15.1 Check all doors for correct opening and closing adjustments and operation 15.2 Inspect condition of door seals 15.3 Check window glass and seal condition 15.4 Check mirror condition and adjustments 15.5 Fill window washer reservoir 15.6 Inspect air con vents condition | PASS NORMAL PASS PASS FAIL PASS PASS PASS PASS PASS PASS PASS PAS |
| 14.3 Check grease line condition 14.4 Refill grease tank 14.5 Lubricate bucket linkage 14.6 Lubricate blade linkage 14.7 Lubricate boom& stick linkage 14.8 Lubricate swing bearing 15.1 Check all doors for correct opening and closing adjustments and operation 15.2 Inspect condition of door seals 15.3 Check window glass and seal condition 15.4 Check mirror condition and adjustments 15.5 Fill window washer reservoir 15.6 Inspect air con vents condition 15.7 Inspect seat belt and mounting hardware | PASS NORMAL PASS PASS PASS FAIL PASS PASS PASS PASS PASS PASS PASS PAS |



| 17.1 All inspections have been completed and rectified as required | NORMAL |
|--|--------|
| 17.2 All safety related defects have been repaired or reported | NORMAL |
| 17.3 All defects have been noted and reported | NORMAL |
| 17.4 All fluids are at correct level and drain plugs tight | NORMAL |
| 17.5 All oil samples have visually been inspected and any notable signs of contamination have been reported | NORMAL |
| 17.6 All replaced filters have been cut and inspected and photos added to CAT Inspect and reported to supervisor | N/A |
| 17.7 Machine has been recommissioned and ready for operation | NORMAL |
| 17.8 PM service notification marked off in Vision Link | NORMAL |
| 18.1 DEFECTS IDENTIFIED | FAIL |
| 19.1 Hydraulic oil | 0 |
| 19.2 Enggine oil | 0 |
| 19.3 Slew oil | 0 |
| 19.4 Gear oil | 0 |



General Info/Comments



General Info/Comments



