

KOBELCO SK235SR-5

Major Service

● 0 ● 12 ● 87 ● 7

| | | | |
|-------------------|---|------------------|---------------------------------|
| Inspection Number | RP056491 | Customer No | 200000 |
| Serial Number | YF08010319 | Customer Name | AUSTRALIAN HAMMER SUPPLIES HIRE |
| Make | KOBELCO | Customer Email | |
| Model | SK235SR-5 | Works Order | RP056491 |
| Equipment Family | 17.1-22.5T HYDRAULIC EXCAVATOR | Completed On | 3/03/2026 2:38:29 PM |
| Asset ID | AHSH108 | Inspector | Collin Graham |
| Location | AUSTRALIAN HAMMER SUPPLIES HIRE Unit 3/32 WILLIAMSON RD INGLEBURN 2565 | PDF Generated On | 03/03/2026 |
| | | Machine Hours | 5987 |
| | | Next Meter | 6500 |
| Customer |  | | |

General Info & Comments

● **General Info/Comments** 6000hr service



TASK SAFETY INSTRUCTIONS

- **1.1 Wear Correct PPE at all times** PASS
- **1.2 All isolation and safe work procedures must be followed** PASS

- 1.3 Identify task hazards and controls utilising hierarchy or controls model PASS
- 1.4 Ensure a competent operator and spotter is utilised to move mobile equipment PASS
- 1.5 Ensure all mobile equipment is fundamentally stable PASS
- 1.6 Ensure three points of contact is maintained during access and egress PASS
- 1.7 Ensure acceptable housekeeping standards are maintained at all times PASS

MACHINE GENERAL RUNNINGCHECKS

- 2.1 Check all work lights, beacon & reverse alarmfor operation PASS
- 2.2 Test all dash warning lights, gauges and audible alarms for correct operation PASS
- 2.3 Check idle timer for correct shut down operation PASS
- 2.4 Check operation of all three emergency stop buttons PASS
- 2.5 Check operation of horn PASS
- 2.6 Check operation of reverse camera PASS
- 2.7 Check alternator charge voltage PASS
- 2.8 Check operation of auto grease systemby manually activating timer N/A
- 2.9 Check fire systemcontrol panel for 'Normal' N/A

PM FIRE SUPPRESSION SYSTEM

- 5.1 Ensure fire suppression bottle and components are securely mounted and in good condition N/A
- 5.2 Ensure fire suppression is correctly charged N/A
- 5.3 Inspect last charge date DATE:2026-03-04T00:00:00.000000
- 5.4 Check all fire extinguishers are securely mounted and in good condition PASS
- 5.5 Check all fire extinguishers are correctly charged PASS

● 5.6 Inspect last charge date

DATE:2026-03-04T00:00:00.0000000

PM ENGINE

● 6.1 Perform engine valve set

N/A

● 6.2 Inspect air intake system hoses, pipes, clamps for signs of dirt ingress

PASS

● 6.3 Inspect engine for oil or fuel leaks

PASS

● 6.4 Inspect engine components for missing clamps

PASS

● 6.5 Inspect exhaust system for signs of leaks, loose bolts or missing clamps

PASS

● 6.6 Inspect turbo for security and signs of leaks

PASS

● 6.7 Inspect condition of exhaust lagging

PASS

● 6.8 Inspect engine mounts for condition and loose hardware

PASS

● 6.9 Inspect alternator mount condition and adjustment

PASS

● 6.10 Inspect wiring condition and security

PASS

● 6.11 Inspect engine belts

PASS

PM ENGINE COOLING SYSTEM

● 7.1 Check coolant level

PASS

● 7.2 Check condition of radiator cap

PASS

● 7.3 Check condition of radiator core

PASS

● 7.4 Check cooling system for signs of leaks

PASS

● 7.5 Check hose and clamp condition

PASS

● 7.6 Inspect fan condition and operation

PASS

● 7.7 Inspect radiator and fan guard condition

PASS

PM SWING TRANSMISSION

● 8.1 Inspect swing transmission for signs of leaks *PASS*

● 8.2 Inspect swing transmission oil level *PASS*

PM HYDRAULIC SYSTEM

● 9.1 Check hydraulic oil level *PASS*

● 9.2 Inspect hydraulic cylinders for leaks and security *PASS*

● 9.3 Inspect hydraulic hoses for leaks, damage, security *PASS*

● 9.4 Inspect hydraulic pump condition, leaks, security *PASS*

● 9.5 Check Pilot Accumulator operation as per OEM Maintenance Procedure - Test Boom Down Functionality with engine off *PASS*

PM FINAL DRIVES

● 10.1 Inspect LHS final drive mount condition for leaks and security *PASS*

● 10.2 Inspect LHS oil level and mag plug condition *PASS*

● 10.3 Inspect RHS final drive mount condition for leaks and security *PASS*

● 10.4 Inspect RHS oil level and mag plug condition *PASS*

PM UNDERCARRIAGE

● 11.1 Inspect LHS track tension *PASS*

● 11.2 Inspect RHS track tension *PASS*

● 11.3 Inspect tracks for loose/missing bolts *PASS*

● 11.4 Inspect load and carrier rollers for signs of leaks *PASS*

● 11.5 Inspect idlers for signs of leaks *PASS*

● 11.6 Inspect sprocket segments condition *PASS*

● 11.7 Inspect track frame for cracks, lose or missing hardware *PASS*

PM FRAME AND BODY

| | |
|---|------|
| ● 12.1 Check panels for damage and security | PASS |
| ● 12.2 Check access steps and walkway condition | PASS |
| ● 12.3 Inspect boom condition – cracks, missing clamps, damaged pipes, excessive movement, lubrication | PASS |
| ● 12.4 Inspect stick condition – cracks, missing clamps, damaged pipes, excessive movement, lubrication | PASS |
| ● 12.5 Inspect quick hitch condition and operation | PASS |
| ● 12.6 Inspect bucket condition – cracks, wear, damage, mounts | PASS |
| ● 12.7 Inspect GET condition and hardware | PASS |

PM ELECTRICAL SYSTEM

| | |
|--|------|
| ● 13.1 Check battery condition | PASS |
| ● 13.2 Check battery terminal condition | PASS |
| ● 13.3 Check battery security | PASS |
| ● 13.4 Check battery box drain is clear | PASS |
| ● 13.5 Check wiring condition and security | PASS |

PM GREASE SYSTEM

| | |
|--|------|
| ● 14.1 Check all points for acceptable lubrication | PASS |
| ● 14.2 Inspect grease system operation | PASS |
| ● 14.3 Check grease line condition | PASS |
| ● 14.4 Refill grease tank | N/A |
| ● 14.5 Lubricate bucket linkage | PASS |
| ● 14.6 Lubricate blade linkage | PASS |
| ● 14.7 Lubricate boom & stick linkage | PASS |
| ● 14.8 Lubricate swing bearing | PASS |

PM OPERATOR STATION

| | |
|--|------|
| ● 15.1 Check all doors for correct opening and closing adjustments and operation | PASS |
| ● 15.2 Inspect condition of door seals | PASS |
| ● 15.3 Check window glass and seal condition | PASS |
| ● 15.4 Check mirror condition and adjustments | PASS |
| ● 15.5 Fill window washer reservoir | PASS |
| ● 15.6 Inspect air con vents condition | PASS |
| ● 15.7 Inspect seat belt and mounting hardware | PASS |
| ● 15.8 Inspect seat condition, operation and mounting | PASS |
| ● 15.9 Replace cabin A/C filter | PASS |

OIL SAMPLING

| | |
|---------------|------|
| ● 16.1 Engine | PASS |
|---------------|------|

PM POST SERVICE INSPECTION CHECKS

| | |
|--|------|
| ● 17.1 All inspections have been completed and rectified as required | PASS |
| ● 17.2 All safety related defects have been repaired or reported | PASS |
| ● 17.3 All defects have been noted and reported | PASS |
| ● 17.4 All fluids are at correct level and drain plugs tight | PASS |
| ● 17.5 All oil samples have visually been inspected and any notable signs of contamination have been reported | PASS |
| ● 17.6 All replaced filters have been cut and inspected and photos added to CAT Inspect and reported to supervisor | PASS |
| ● 17.7 Machine has been recommissioned and ready for operation | PASS |
| ● 17.8 PM service notification marked off in Vision Link | N/A |

DEFECTS IDENTIFIED

● 18.1 DEFECTS IDENTIFIED na

OIL USED

● 19.1 Hydraulic oil 60

● 19.2 Engine oil 18

● 19.3 Slew oil 0

● 19.4 Gear oil 10

● 19.5 Coolant 0

● Site photo

● Site photo