

## FITFLEET-EXCAVATOR-250HR-CVA

## PM Checklist

• 3 • 0 • 93 • 9

Inspection Number	21756100	Customer No	2969824372
Serial Number	KFE10070	Customer Name	AUSTRALIAN HAMMER SUPPLIES HIRE PTY LTD
Make	CATERPILLAR	Customer Email	hirebookings2@hammer hire.com.au
Model	320	Work Order	sc74846
Equipment Family	Medium Hydraulic Excavator	Completed On	19/03/2025 1:38:37 PM
Asset ID	AHSH137	Inspector	Collin Graham
SMU	2688 Hours	PDF Generated On	19/03/2025
Location	38 Wharf Rd, Melrose Park, New South Wales 2114, Australia	Coordinates	0, 0, 0

Technician

- philas

## **General Info & Comments**

## General info/Comments

Comments: Overheating issues for engine These are due to coolant leak at hoses under engine accessible via belly plate





ACTION

TASK SAFETY INSTRUCTIONS - Revision Number: 02 D	ate: 25th September 2023
• 1.1 Wear Correct PPE at all times	PASS
1.2 All isolation and safe work procedures must be for	llowed PASS
1.3 Identify task hazards and controls utilising hierard	chy or controls model PASS
<ul> <li>1.4 Ensure a competent operator and spotter is utilise equipment</li> </ul>	ed to move mobile PASS
<ul> <li>1.5 Ensure all mobile equipment is fundamentally sta</li> </ul>	ble PASS
<ul> <li>1.6 Ensure three points of contact is maintained during</li> </ul>	ng access and egress PASS
1.7 Ensure acceptable housekeeping standards are not standards	naintained at all times PASS
MACHINE GENERAL RUNNING CHECKS	
• 2.1 Check all work lights, beacon & reverse alarm for	operation PASS
• 2.2 Test all dash warning lights, gauges and audible	alarms for correct operation PASS
• 2.3 Check idle timer for correct shut down operation	PASS
• 2.4 Check operation of all three emergency stop butter	ons PASS
2.5 Check operation of horn	PASS
2.6 Check operation of reverse camera	PASS
2.7 Check alternator charge voltage - ACTUAL	_V PASS
2.8 Check operation of auto grease system by manual	ally activating timer N/A
• 2.9 Check fire system control panel for 'Normal'	N/A
orm Order Report Serial Number : KFE100	70 Asset ID: AHSH137 Page 2

2.10 Test hydraulic lock out function operation	PASS
2.11 Check window wiper and washer operation	PASS
PM SAFETY GENERAL INSPECTION	
3.1 Visually ensure all guards, shields and covers are in place and in good condition to ensure personal are protected from rotating parts	PASS
3.2 Check condition of machine identification signage	PASS
3.3 Inspect ROPS/FOPS condition	PASS
PM BRAKING SYSTEM	
4.1 Test travel brakes – Ensure the machine comes to a stop when travel controls are released	PASS
4.2 Test travel brakes – Ensure the brakes hold on a suitable slope	PASS
PM FIRE SUPPRESSION SYSTEM	
5.1 Ensure fire suppression bottle and components are securely mounted and in good condition	N/A
5.2 Ensure fire suppression is correctly charged	N/A
5.3 Inspect last charge date - ACTUAL	N/A
5.4 Check all fire extinguishers are securely mounted and in good condition	PASS
5.5 Check all fire extinguishers are correctly charged	PASS
5.6 Inspect last charge date - ACTUAL	PASS
PMENGINE	
6.1 Perform engine valve set	N/A
Order Report Serial Number : KFE10070 Asset ID : AHSH137	Pa

6.2 Inspect air intake system hoses, pipes, clamps for signs of dirt ingress	PASS
6.3 Inspect engine for oil or fuel leaks	PASS
6.4 Inspect engine components for missing clamps	PASS
6.5 Inspect exhaust system for signs of leaks, loose bolts or missing clamps	PASS
6.6 Inspect turbo for security and signs of leaks	PASS
6.7 Inspect condition of exhaust lagging	PASS
6.8 Inspect engine mounts for condition and loose hardware	PASS
6.9 Inspect alternator mount condition and adjustment	PASS
6.10 Inspect wiring condition and security	PASS
6.11 Inspect engine belts	PASS
PM ENGINE COOLING SYSTEM	
7.1 Check coolant level	FAIL
Comments: Coolant leak	
7.2 Check condition of radiator cap	PASS
7.3 Check condition of radiator core	PASS
7.4 Check cooling system for signs of leaks	FAIL
Comments: Coolant leak	
	PASS

PM SWING TRANSMISSION	
8.1 Inspect swing transmission for signs of leaks	PASS
8.2 Inspect swing transmission oil level	PASS
PM HYDRAULIC SYSTEM	
9.1 Check hydraulic oil level	PASS
9.2 Inspect hydraulic cylinders for leaks and security	PASS
9.3 Inspect hydraulic hoses for leaks, damage, security	PASS
9.4 Inspect hydraulic pump condition, leaks, security	PASS
<ul> <li>9.5 Check Pilot Accumulator operation as per OEM Maintenance Procedure - Test Boom Down Functionality with engine off</li> </ul>	PASS
PM FINAL DRIVES	
10.1 Inspect LHS final drive mount condition for leaks and security	PASS
10.2 Inspect LHS oil level and mag plug condition	PASS
10.3 Inspect RHS final drive mount condition for leaks and security	PASS
10.4 Inspect RHS oil level and mag plug condition	PASS
PMUNDERCARRIAGE	
11.1 Inspect LHS track tension	PASS
11.2 Inspect RHS track tension	PASS
11.3 Inspect tracks for loose/missing bolts	PASS

11.4 Inspect load and carrier rollers for signs of leaks	PASS
11.5 Inspect idlers for signs of leaks	PASS
11.6 Inspect sprocket segments condition	PASS
11.7 Inspect track frame for cracks, lose or missing hardware	PASS
PM FRAME AND BODY	
12.1 Check panels for damage and security	PASS
12.2 Check access steps and walkway condition	PASS
<ul> <li>12.3 Inspect boom condition – cracks, missing clamps, damaged pipes, excessive movement, lubrication</li> </ul>	PASS
<ul> <li>12.4 Inspect stick condition – cracks, missing clamps, damaged pipes, excessive movement, lubrication</li> </ul>	PASS
12.5 Inspect quick hitch condition and operation	PASS
12.6 Inspect bucket condition – cracks, wear, damage, mounts	PASS
12.7 Inspect GET condition and hardware	PASS
PM ELECTRICAL SYSTEM	
13.1 Check battery condition	PASS
13.2 Check battery terminal condition	PASS
13.3 Check battery security	PASS
<ul> <li>13.4 Check battery box drain is clear</li> </ul>	PASS
13.5 Check wiring condition and security	PASS

PM GREASE SYSTEM	
14.1 Check all points for acceptable lubrication	PASS
14.2 Inspect grease system operation	PASS
14.3 Check grease line condition	PASS
14.4 Refill grease tank	N/A
14.5 Lubricate bucket linkage	PASS
14.6 Lubricate blade linkage	N/A
14.7 Lubricate boom & stick linkage	PASS
14.8 Lubricate swing bearing	PASS
PM OPERATOR STATION	
15.1 Check all doors for correct opening and closing adjustments and operation	PASS
15.2 Inspect condition of door seals	PASS
15.3 Check window glass and seal condition	PASS
15.4 Check mirror condition and adjustments	PASS
15.5 Fill window washer reservoir	PASS
15.6 Inspect air con vents condition	PASS
15.7 Inspect seat belt and mounting hardware	PASS
15.8 Inspect seat condition, operation and mounting	PASS

	15.9 Replace cabin A/C filter	N/A
0	L SAMPLING	
•	16.1 Engine	PASS
P	M POST SERVICE INSPECTION CHECKS	
•	17.1 All inspections have been completed and rectified as required	PASS
•	17.2 All safety related defects have been repaired or reported	PASS
•	17.3 All defects have been noted and reported	PASS
•	17.4 All fluids are at correct level and drain plugs tight	PASS
•	17.5 All oil samples have visually been inspected and any notable signs of contamination have been reported	PASS
•	17.6 All replaced filters have been cut and inspected and photos added to CAT Inspect and reported to supervisor	PASS
•	17.7 Machine has been recommissioned and ready for operation	PASS
•	17.8 PM service notification marked off in Vision Link	COMPLETED
D	EFECTS IDENTIFIED	
•	18.1 DEFECTS IDENTIFIED	PASS