



Australian Hammer Supplies Hire
Unit 3/32 Williamson Road
Ingleburn
NSW 2565

CATERPILLAR CAT335F

Major Service



● 4 ● 0 ● 85 ● 8

Inspection Number	RP050916	Customer No	
Serial Number	SGJ20461	Customer Name	
Make	CATERPILLAR	Customer Email	
Model	CAT335F	Works Order	RP050916
Equipment Family	35.1-40T HYDRAULIC EXCAVATOR	Completed On	7/07/2025 7:36:12 AM
Asset ID	AHSH160	Inspector	Jake Raffen
Location	AUSTRILAN HAMMER SUPPLIES HIRE Unit 3/32 WILLIAMSON RD INGLEBURN 2565	PDF Generated On	07/07/2025
		Machine Hours	
		Next Meter	7606
Customer			

General Info & Comments

General Info/Comments

500hr service - all defects found on dehire and tagged on machine. Turbo wastegate solenoid failed. Sent email to parts for ordering



TASK SAFETY INSTRUCTIONS

- | | |
|--|--------|
| 1.1 Wear Correct PPE at all times | NORMAL |
| 1.2 All isolation and safe work procedures must be followed | NORMAL |
| 1.3 Identify task hazards and controls utilising hierarchy or controls model | NORMAL |
| 1.4 Ensure a competent operator and spotter is utilised to move mobile equipment | NORMAL |
| 1.5 Ensure all mobile equipment is fundamentally stable | NORMAL |
| 1.6 Ensure three points of contact is maintained during access and egress | NORMAL |

- | | |
|---|--------|
| <input checked="" type="radio"/> 1.7 Ensure acceptable housekeeping standards are maintained at all times | NORMAL |
|---|--------|

MACHINE GENERAL RUNNINGCHECKS

- | | |
|--|------|
| <input checked="" type="radio"/> 2.1 Check all work lights, beacon & reverse alarmfor operation | PASS |
| <input checked="" type="radio"/> 2.2 Test all dash warning lights, gauges and audible alarms for correct operation | PASS |
| <input type="radio"/> 2.3 Check idle timer for correct shut down operation | N/A |
| <input checked="" type="radio"/> 2.4 Check operation of all three emergency stop buttons | PASS |
| <input checked="" type="radio"/> 2.5 Check operation of horn | PASS |
| <input checked="" type="radio"/> 2.6 Check operation of reverse camera | PASS |
| <input checked="" type="radio"/> 2.7 Check alternator charge voltage - ACTUAL_____V | PASS |
| <input type="radio"/> 2.8 Check operation of auto grease systemby manually activating timer | N/A |
| <input type="radio"/> 2.9 Check fire systemcontrol panel for 'Normal' | N/A |

PM FIRE SUPPRESSION SYSTEM

- | | |
|---|------|
| <input checked="" type="radio"/> 5.1 Ensure fire suppression bottle and components are securely mounted and in good condition | PASS |
| <input checked="" type="radio"/> 5.2 Ensure fire suppression is correctly charged | PASS |
| <input checked="" type="radio"/> 5.3 Inspect last charge date - ACTUAL _____ | PASS |
| <input checked="" type="radio"/> 5.4 Check all fire extinguishers are securely mounted and in good condition | PASS |
| <input checked="" type="radio"/> 5.5 Check all fire extinguishers are correctly charged | PASS |
| <input checked="" type="radio"/> 5.6 Inspect last charge date - ACTUAL _____ | PASS |

PM ENGINE

- | | |
|--|------|
| <input type="radio"/> 6.1 Performengine valve set | N/A |
| <input checked="" type="radio"/> 6.2 Inspect air intake systemhoses, pipes, clamps for signs of dirt ingress | PASS |
| <input checked="" type="radio"/> 6.3 Inspect engine for oil or fuel leaks | PASS |

● 6.4 Inspect engine components for missing clamps	PASS
● 6.5 Inspect exhaust systemfor signs of leaks, loose bolts or missing clamps	PASS
● 6.6 Inspect turbo for security and signs of leaks	PASS
● 6.7 Inspect condition of exhaust lagging	PASS
● 6.8 Inspect engine mounts for condition and loose hardware	PASS
● 6.9 Inspect alternator mount condition and adjustment	PASS
● 6.10 Inspect wiring condition and security	PASS
● 6.11 Inspect engine belts	PASS

PM ENGINE COOLINGSYSTEM

● 7.1 Check coolant level	PASS
● 7.2 Check condition of radiator cap	PASS
● 7.3 Check condition of radiator core	PASS
● 7.4 Check cooling systemfor signs of leaks	PASS
● 7.5 Check hose and clamp condition	PASS
● 7.6 Inspect fan condition and operation	PASS
● 7.7 Inspect radiator and fan guard condition	PASS

PM SWINGTRANSMISSION

● 8.1 Inspect swing transmission for signs of leaks	PASS
● 8.2 Inspect swing transmission oil level	PASS

PM HYDRAULIC SYSTEM

● 9.1 Check hydraulic oil level	PASS
● 9.2 Inspect hydraulic cylinders for leaks and security	PASS
● 9.3 Inspect hydraulic hoses for leaks, damage, security	PASS

●	9.4 Inspect hydraulic pump condition, leaks, security	PASS
---	---	------

●	9.5 Check Pilot Accumulator operation as per OEM Maintenance Procedure - Test Boom Down Functionality with engine off	PASS
---	---	------

PM FINAL DRIVES

●	10.1 Inspect LHS final drive mount condition for leaks and security	PASS
---	---	------

●	10.2 Inspect LHS oil level and mag plug condition	PASS
---	---	------

●	10.3 Inspect RHS final drive mount condition for leaks and security	PASS
---	---	------

●	10.4 Inspect RHS oil level and mag plug condition	PASS
---	---	------

PM UNDERCARRIAGE

●	11.1 Inspect LHS track tension	PASS
---	--------------------------------	------

●	11.2 Inspect RHS track tension	PASS
---	--------------------------------	------

●	11.3 Inspect tracks for loose/missing bolts	PASS
---	---	------

●	11.4 Inspect load and carrier rollers for signs of leaks	PASS
---	--	------

●	11.5 Inspect idlers for signs of leaks	PASS
---	--	------

●	11.6 Inspect sprocket segments condition	PASS
---	--	------

●	11.7 Inspect track frame for cracks, lose or missing hardware	PASS
---	---	------

PM FRAME AND BODY

●	12.1 Check panels for damage and security	FAIL
---	---	------

●	12.2 Check access steps and walkway condition	NORMAL
---	---	--------

●	12.3 Inspect boom condition – cracks, missing clamps, damaged pipes, excessive movement, lubrication	PASS
---	--	------

●	12.4 Inspect stick condition – cracks, missing clamps, damaged pipes, excessive movement, lubrication	PASS
---	---	------

●	12.5 Inspect quick hitch condition and operation	FAIL
---	--	------

●	12.6 Inspect bucket condition – cracks, wear, damage, mounts	N/A
---	--	-----

● 12.7 Inspect GET condition and hardware	N/A
---	-----

PM ELECTRICAL SYSTEM

● 13.1 Check battery condition	PASS
● 13.2 Check battery terminal condition	PASS
● 13.3 Check battery security	PASS
● 13.4 Check battery box drain is clear	PASS
● 13.5 Check wiring condition and security	PASS

PM GREASE SYSTEM

● 14.1 Check all points for acceptable lubrication	PASS
● 14.2 Inspect grease system operation	PASS
● 14.3 Check grease line condition	PASS
● 14.4 Refill grease tank	N/A
● 14.5 Lubricate bucket linkage	PASS
● 14.6 Lubricate blade linkage	PASS
● 14.7 Lubricate boom & stick linkage	PASS
● 14.8 Lubricate swing bearing	PASS

PM OPERATOR STATION

● 15.1 Check all doors for correct opening and closing adjustments and operation	PASS
● 15.2 Inspect condition of door seals	PASS
● 15.3 Check window glass and seal condition	PASS
● 15.4 Check mirror condition and adjustments	PASS
● 15.5 Fill window washer reservoir	N/A
● 15.6 Inspect air con vents condition	PASS

●	15.7 Inspect seat belt and mounting hardware	PASS
---	--	------

●	15.8 Inspect seat condition, operation and mounting	PASS
---	---	------

●	15.9 Replace cabin A/C filter	FAIL
---	-------------------------------	------

OIL SAMPLING

●	16.1 Engine	PASS
---	-------------	------

PM POST SERVICE INSPECTION CHECKS

●	17.1 All inspections have been completed and rectified as required	NORMAL
---	--	--------

●	17.2 All safety related defects have been repaired or reported	NORMAL
---	--	--------

●	17.3 All defects have been noted and reported	NORMAL
---	---	--------

●	17.4 All fluids are at correct level and drain plugs tight	NORMAL
---	--	--------

●	17.5 All oil samples have visually been inspected and any notable signs of contamination have been reported	NORMAL
---	---	--------

●	17.6 All replaced filters have been cut and inspected and photos added to CAT Inspect and reported to supervisor	NORMAL
---	---	--------

●	17.7 Machine has been recommissioned and ready for operation	NORMAL
---	--	--------

●	17.8 PM service notification marked off in Vision Link	NORMAL
---	--	--------

DEFECTS IDENTIFIED

●	18.1 DEFECTS IDENTIFIED	FAIL
---	-------------------------	------