



## KUBOTA U55-4 EXCAVATOR

### Minor Service

● 1 ● 12 ● 85 ● 8

Inspection Number RP057313

Customer No 200000

Serial Number 26535

Customer Name AUSTRALIAN HAMMER  
SUPPLIES HIRE

Make KUBOTA

Customer Email

Model U55-4

Works Order RP057313

Equipment Family 4.1-6T HYDRAULIC EXCAVATOR

Completed On 5/03/2026 11:21:13 AM

Asset ID AHS186

Inspector Reid Lewis

Location AUSTRALIAN HAMMER SUPPLIES HIRE  
Unit 3/32 WILLIAMSON RD  
  
INGLEBURN  
2565

PDF Generated On 05/03/2026

Machine Hours 1741

Next Meter 2000

Customer

### General Info & Comments

● General Info/Comments

meter reading  
 wrong correct  
 hours are 1741.4  
 completed 250hr  
 service and  
 inspection



**TASK SAFETY INSTRUCTIONS**

- |  |      |
|--|------|
| ● 1.1 Wear Correct PPE at all times  | PASS |
| ● 1.2 All isolation and safe work procedures must be followed                      | PASS |
| ● 1.3 Identify task hazards and controls utilising hierarchy or controls model     | PASS |
| ● 1.4 Ensure a competent operator and spotter is utilised to move mobile equipment | PASS |
| ● 1.5 Ensure all mobile equipment is fundamentally stable                          | PASS |
| ● 1.6 Ensure three points of contact is maintained during access and egress        | PASS |
| ● 1.7 Ensure acceptable housekeeping standards are maintained at all times         | PASS |

## MACHINE GENERAL RUNNINGCHECKS

●	2.1 Check all work lights, beacon & reverse alarm for operation	PASS
●	2.2 Test all dash warning lights, gauges and audible alarms for correct operation	PASS
●	2.3 Check idle timer for correct shut down operation	PASS
●	2.4 Check operation of all three emergency stop buttons	PASS
●	2.5 Check operation of horn	PASS
●	2.6 Check operation of reverse camera	FAIL
●	2.7 Check alternator charge voltage	PASS
●	2.8 Check operation of auto grease system by manually activating timer	N/A
●	2.9 Check fire system control panel for 'Normal'	N/A

## PM FIRE SUPPRESSION SYSTEM

●	5.1 Ensure fire suppression bottle and components are securely mounted and in good condition	N/A
●	5.2 Ensure fire suppression is correctly charged	N/A
●	5.3 Inspect last charge date	DATE:2026-03-05T00:00:00.0000000
●	5.4 Check all fire extinguishers are securely mounted and in good condition	PASS
●	5.5 Check all fire extinguishers are correctly charged	PASS
●	5.6 Inspect last charge date	DATE:2026-03-05T00:00:00.0000000

## PM ENGINE

●	6.1 Perform engine valve set	PASS
●	6.2 Inspect air intake system hoses, pipes, clamps for signs of dirt ingress	PASS
●	6.3 Inspect engine for oil or fuel leaks	PASS

● 6.4 Inspect engine components for missing clamps	PASS
● 6.5 Inspect exhaust system for signs of leaks, loose bolts or missing clamps	PASS
● 6.6 Inspect turbo for security and signs of leaks	PASS
● 6.7 Inspect condition of exhaust lagging	PASS
● 6.8 Inspect engine mounts for condition and loose hardware	PASS
● 6.9 Inspect alternator mount condition and adjustment	PASS
● 6.10 Inspect wiring condition and security	PASS
● 6.11 Inspect engine belts	PASS

## PM ENGINE COOLING SYSTEM

● 7.1 Check coolant level	PASS
● 7.2 Check condition of radiator cap	PASS
● 7.3 Check condition of radiator core	PASS
● 7.4 Check cooling system for signs of leaks	PASS
● 7.5 Check hose and clamp condition	PASS
● 7.6 Inspect fan condition and operation	PASS
● 7.7 Inspect radiator and fan guard condition	PASS

## PM SWING TRANSMISSION

● 8.1 Inspect swing transmission for signs of leaks	PASS
● 8.2 Inspect swing transmission oil level	N/A

## PM HYDRAULIC SYSTEM

● 9.1 Check hydraulic oil level	PASS
● 9.2 Inspect hydraulic cylinders for leaks and security	PASS
● 9.3 Inspect hydraulic hoses for leaks, damage, security	PASS

● 9.4 Inspect hydraulic pump condition, leaks, security *PASS*

● 9.5 Check Pilot Accumulator operation as per OEM Maintenance Procedure - Test Boom Down Functionality with engine off *PASS*

## PM FINAL DRIVES

● 10.1 Inspect LHS final drive mount condition for leaks and security *PASS*

● 10.2 Inspect LHS oil level and mag plug condition *PASS*

● 10.3 Inspect RHS final drive mount condition for leaks and security *PASS*

● 10.4 Inspect RHS oil level and mag plug condition *PASS*

## PM UNDERCARRIAGE

● 11.1 Inspect LHS track tension *PASS*

● 11.2 Inspect RHS track tension *PASS*

● 11.3 Inspect tracks for loose/missing bolts *PASS*

● 11.4 Inspect load and carrier rollers for signs of leaks *PASS*

● 11.5 Inspect idlers for signs of leaks *PASS*

● 11.6 Inspect sprocket segments condition *PASS*

● 11.7 Inspect track frame for cracks, lose or missing hardware *PASS*

## PM FRAME AND BODY

● 12.1 Check panels for damage and security *PASS*

● 12.2 Check access steps and walkway condition *PASS*

● 12.3 Inspect boom condition – cracks, missing clamps, damaged pipes, excessive movement, lubrication *PASS*

● 12.4 Inspect stick condition – cracks, missing clamps, damaged pipes, excessive movement, lubrication *PASS*

● 12.5 Inspect quick hitch condition and operation *PASS*

● 12.6 Inspect bucket condition – cracks, wear, damage, mounts *PASS*

● 12.7 Inspect GET condition and hardware PASS

**PM ELECTRICAL SYSTEM**

● 13.1 Check battery condition PASS

● 13.2 Check battery terminal condition PASS

● 13.3 Check battery security PASS

● 13.4 Check battery box drain is clear PASS

● 13.5 Check wiring condition and security PASS

**PM GREASE SYSTEM**

● 14.1 Check all points for acceptable lubrication PASS

● 14.2 Inspect grease system operation N/A

● 14.3 Check grease line condition N/A

● 14.4 Refill grease tank N/A

● 14.5 Lubricate bucket linkage PASS

● 14.6 Lubricate blade linkage PASS

● 14.7 Lubricate boom & stick linkage PASS

● 14.8 Lubricate swing bearing PASS

**PM OPERATOR STATION**

● 15.1 Check all doors for correct opening and closing adjustments and operation PASS

● 15.2 Inspect condition of door seals PASS

● 15.3 Check window glass and seal condition PASS

● 15.4 Check mirror condition and adjustments PASS

● 15.5 Fill window washer reservoir PASS

● 15.6 Inspect air con vents condition PASS

- |   |      |
|---|------|
| ● 15.7 Inspect seat belt and mounting hardware        | PASS |
| ● 15.8 Inspect seat condition, operation and mounting | PASS |
| ● 15.9 Replace cabin A/C filter                       | PASS |

#### OIL SAMPLING

- |               |      |
|---------------|------|
| ● 16.1 Engine | PASS |
|---------------|------|

#### PM POST SERVICE INSPECTION CHECKS

- |  |      |
|--|------|
| ● 17.1 All inspections have been completed and rectified as required   | PASS |
| ● 17.2 All safety related defects have been repaired or reported   | PASS |
| ● 17.3 All defects have been noted and reported  | PASS |
| ● 17.4 All fluids are at correct level and drain plugs tight   | PASS |
| ● 17.5 All oil samples have visually been inspected and any notable signs of contamination have been reported      | PASS |
| ● 17.6 All replaced filters have been cut and inspected and photos added to CAT Inspect and reported to supervisor | PASS |
| ● 17.7 Machine has been recommissioned and ready for operation   | PASS |
| ● 17.8 PM service notification marked off in Vision Link   | PASS |

#### DEFECTS IDENTIFIED

- |                           |  |
|---------------------------|--|
| ● 18.1 DEFECTS IDENTIFIED | <i>reverse camera monitor broken requires whole new unit as monitors we have in stock dont connect</i> |
|---------------------------|--|

#### OIL USED

- |                      |    |
|----------------------|----|
| ● 19.1 Hydraulic oil | 4  |
| ● 19.2 Engine oil    | 12 |
| ● 19.3 Slew oil      | 0  |

---

● 19.4 Gear oil	2
● 19.5 Coolant	0

---