



KUBOTA EXCAVATOR U35

Major Service

● 1 ● 14 ● 82 ● 11

Inspection Number	RP051948	Customer No	200000
Serial Number	25827	Customer Name	AUSTRALIAN HAMMER SUPPLIES HIRE
Make	KUBOTA	Customer Email	
Model	U35-4HG (O)	Works Order	RP051948
Equipment Family	2.1-4.0 HYDRAULIC EXCAVATOR	Completed On	25/02/2026 10:05:33 AM
Asset ID	AHSH192	Inspector	Etienne Llanos
Location	AUSTRALIAN HAMMER SUPPLIES HIRE Unit 3/32 WILLIAMSON RD INGLEBURN 2565	PDF Generated On	25/02/2026
		Machine Hours	447
Customer		Next Meter	750

General Info & Comments

● **General Info/Comments**

furst 500hr service



TASK SAFETY INSTRUCTIONS

- | | |
|--|------|
| ● 1.1 Wear Correct PPE at all times | PASS |
| ● 1.2 All isolation and safe work procedures must be followed | PASS |
| ● 1.3 Identify task hazards and controls utilising hierarchy or controls model | PASS |
| ● 1.4 Ensure a competent operator and spotter is utilised to move mobile equipment | PASS |
| ● 1.5 Ensure all mobile equipment is fundamentally stable | PASS |
| ● 1.6 Ensure three points of contact is maintained during access and egress | PASS |
| ● 1.7 Ensure acceptable housekeeping standards are maintained at all times | PASS |

MACHINE GENERAL RUNNINGCHECKS

<input checked="" type="radio"/>	2.1 Check all work lights, beacon & reverse alarm for operation	PASS
<input checked="" type="radio"/>	2.2 Test all dash warning lights, gauges and audible alarms for correct operation	PASS
<input checked="" type="radio"/>	2.3 Check idle timer for correct shut down operation	PASS
<input checked="" type="radio"/>	2.4 Check operation of all three emergency stop buttons	PASS
<input checked="" type="radio"/>	2.5 Check operation of horn	PASS
<input type="radio"/>	2.6 Check operation of reverse camera	N/A
<input checked="" type="radio"/>	2.7 Check alternator charge voltage	PASS
<input type="radio"/>	2.8 Check operation of auto grease system by manually activating timer	N/A
<input type="radio"/>	2.9 Check fire system control panel for 'Normal'	N/A

PM FIRE SUPPRESSION SYSTEM

<input type="radio"/>	5.1 Ensure fire suppression bottle and components are securely mounted and in good condition	N/A
<input type="radio"/>	5.2 Ensure fire suppression is correctly charged	N/A
<input checked="" type="radio"/>	5.3 Inspect last charge date	DATE:2026-02-25T00:00:00.000000
<input checked="" type="radio"/>	5.4 Check all fire extinguishers are securely mounted and in good condition	PASS
<input checked="" type="radio"/>	5.5 Check all fire extinguishers are correctly charged	PASS
<input checked="" type="radio"/>	5.6 Inspect last charge date	DATE:2026-01-15T00:00:00.000000

PM ENGINE

<input type="radio"/>	6.1 Perform engine valve set	N/A
<input checked="" type="radio"/>	6.2 Inspect air intake system hoses, pipes, clamps for signs of dirt ingress	PASS
<input checked="" type="radio"/>	6.3 Inspect engine for oil or fuel leaks	PASS
<input checked="" type="radio"/>	6.4 Inspect engine components for missing clamps	PASS

● 6.5 Inspect exhaust system for signs of leaks, loose bolts or missing clamps	PASS
● 6.6 Inspect turbo for security and signs of leaks	PASS
● 6.7 Inspect condition of exhaust lagging	PASS
● 6.8 Inspect engine mounts for condition and loose hardware	PASS
● 6.9 Inspect alternator mount condition and adjustment	PASS
● 6.10 Inspect wiring condition and security	PASS
● 6.11 Inspect engine belts	PASS

PM ENGINE COOLING SYSTEM

● 7.1 Check coolant level	PASS
● 7.2 Check condition of radiator cap	PASS
● 7.3 Check condition of radiator core	FAIL
● 7.4 Check cooling system for signs of leaks	PASS
● 7.5 Check hose and clamp condition	PASS
● 7.6 Inspect fan condition and operation	PASS
● 7.7 Inspect radiator and fan guard condition	PASS

PM SWING TRANSMISSION

● 8.1 Inspect swing transmission for signs of leaks	PASS
● 8.2 Inspect swing transmission oil level	PASS

PM HYDRAULIC SYSTEM

● 9.1 Check hydraulic oil level	PASS
● 9.2 Inspect hydraulic cylinders for leaks and security	PASS
● 9.3 Inspect hydraulic hoses for leaks, damage, security	PASS
● 9.4 Inspect hydraulic pump condition, leaks, security	PASS

- 9.5 Check Pilot Accumulator operation as per OEM Maintenance Procedure - Test Boom Down Functionality with engine off *PASS*

PM FINAL DRIVES

- 10.1 Inspect LHS final drive mount condition for leaks and security *PASS*
- 10.2 Inspect LHS oil level and mag plug condition *PASS*
- 10.3 Inspect RHS final drive mount condition for leaks and security *PASS*
- 10.4 Inspect RHS oil level and mag plug condition *PASS*

PM UNDERCARRIAGE

- 11.1 Inspect LHS track tension *PASS*
- 11.2 Inspect RHS track tension *PASS*
- 11.3 Inspect tracks for loose/missing bolts *PASS*
- 11.4 Inspect load and carrier rollers for signs of leaks *PASS*
- 11.5 Inspect idlers for signs of leaks *PASS*
- 11.6 Inspect sprocket segments condition *PASS*
- 11.7 Inspect track frame for cracks, lose or missing hardware *PASS*

PM FRAME AND BODY

- 12.1 Check panels for damage and security *PASS*
- 12.2 Check access steps and walkway condition *PASS*
- 12.3 Inspect boom condition – cracks, missing clamps, damaged pipes, excessive movement, lubrication *PASS*
- 12.4 Inspect stick condition – cracks, missing clamps, damaged pipes, excessive movement, lubrication *PASS*
- 12.5 Inspect quick hitch condition and operation *PASS*
- 12.6 Inspect bucket condition – cracks, wear, damage, mounts *PASS*
- 12.7 Inspect GET condition and hardware *PASS*

PM ELECTRICAL SYSTEM

<input checked="" type="radio"/> 13.1 Check battery condition	PASS
<input checked="" type="radio"/> 13.2 Check battery terminal condition	PASS
<input checked="" type="radio"/> 13.3 Check battery security	PASS
<input checked="" type="radio"/> 13.4 Check battery box drain is clear	PASS
<input checked="" type="radio"/> 13.5 Check wiring condition and security	PASS

PM GREASE SYSTEM

<input checked="" type="radio"/> 14.1 Check all points for acceptable lubrication	PASS
<input type="radio"/> 14.2 Inspect grease system operation	N/A
<input checked="" type="radio"/> 14.3 Check grease line condition	PASS
<input type="radio"/> 14.4 Refill grease tank	N/A
<input checked="" type="radio"/> 14.5 Lubricate bucket linkage	PASS
<input checked="" type="radio"/> 14.6 Lubricate blade linkage	PASS
<input checked="" type="radio"/> 14.7 Lubricate boom & stick linkage	PASS
<input checked="" type="radio"/> 14.8 Lubricate swing bearing	PASS

PM OPERATOR STATION

<input checked="" type="radio"/> 15.1 Check all doors for correct opening and closing adjustments and operation	PASS
<input checked="" type="radio"/> 15.2 Inspect condition of door seals	PASS
<input checked="" type="radio"/> 15.3 Check window glass and seal condition	PASS
<input checked="" type="radio"/> 15.4 Check mirror condition and adjustments	PASS
<input checked="" type="radio"/> 15.5 Fill window washer reservoir	PASS
<input checked="" type="radio"/> 15.6 Inspect air con vents condition	PASS
<input checked="" type="radio"/> 15.7 Inspect seat belt and mounting hardware	PASS

15.8 Inspect seat condition, operation and mounting PASS

15.9 Replace cabin A/C filter N/A

OIL SAMPLING

16.1 Engine PASS

PM POST SERVICE INSPECTION CHECKS

17.1 All inspections have been completed and rectified as required PASS

17.2 All safety related defects have been repaired or reported PASS

17.3 All defects have been noted and reported PASS

17.4 All fluids are at correct level and drain plugs tight PASS

17.5 All oil samples have visually been inspected and any notable signs of contamination have been reported PASS

17.6 All replaced filters have been cut and inspected and photos added to CAT Inspect and reported to supervisor N/A

17.7 Machine has been recommissioned and ready for operation PASS

17.8 PM service notification marked off in Vision Link N/A

DEFECTS IDENTIFIED

18.1 DEFECTS IDENTIFIED *most fins on coolant package bent*

OIL USED

19.1 Hydraulic oil 0

19.2 Engine oil 7

19.3 Slew oil 0

19.4 Gear oil 2

19.5 Coolant 1