



KUBOTA EXCAVATOR U35

Minor Service


● 0 ● 15 ● 68 ● 23

Inspection Number	RP059035	Customer No	200000
Serial Number	25939	Customer Name	AUSTRALIAN HAMMER SUPPLIES HIRE
Make	KUBOTA	Customer Email	
Model	U35-4HG (O)	Works Order	RP059035
Equipment Family	2.1-4.0 HYDRAULIC EXCAVATOR	Completed On	16/04/2026 11:44:16 AM
Asset ID	AHSH198	Inspector	Christian Hartono
Location	AUSTRALIAN HAMMER SUPPLIES HIRE Unit 3/32 WILLIAMSON RD INGLEBURN 2565	PDF Generated On	16/04/2026
		Machine Hours	720
		Next Meter	1000
Customer			

General Info & Comments

● **General Info/Comments**

*1. minor service
 250hr, replaced
 oil, air filter, fuel
 filter ang engine
 oil filter*



TASK SAFETY INSTRUCTIONS

- | | |
|--|------|
| ● 1.1 Wear Correct PPE at all times | PASS |
| ● 1.2 All isolation and safe work procedures must be followed | PASS |
| ● 1.3 Identify task hazards and controls utilising hierarchy or controls model | PASS |
| ● 1.4 Ensure a competent operator and spotter is utilised to move mobile equipment | PASS |
| ● 1.5 Ensure all mobile equipment is fundamentally stable | PASS |
| ● 1.6 Ensure three points of contact is maintained during access and egress | PASS |
| ● 1.7 Ensure acceptable housekeeping standards are maintained at all times | PASS |

MACHINE GENERAL RUNNINGCHECKS

<input checked="" type="radio"/>	2.1 Check all work lights, beacon & reverse alarm for operation	PASS
<input checked="" type="radio"/>	2.2 Test all dash warning lights, gauges and audible alarms for correct operation	PASS
<input checked="" type="radio"/>	2.3 Check idle timer for correct shut down operation	PASS
<input checked="" type="radio"/>	2.4 Check operation of all three emergency stop buttons	PASS
<input checked="" type="radio"/>	2.5 Check operation of horn	PASS
<input type="radio"/>	2.6 Check operation of reverse camera	N/A
<input checked="" type="radio"/>	2.7 Check alternator charge voltage	PASS
<input type="radio"/>	2.8 Check operation of auto grease system by manually activating timer	N/A
<input type="radio"/>	2.9 Check fire system control panel for 'Normal'	N/A

PM FIRE SUPPRESSION SYSTEM

<input type="radio"/>	5.1 Ensure fire suppression bottle and components are securely mounted and in good condition	N/A
<input type="radio"/>	5.2 Ensure fire suppression is correctly charged	N/A
<input checked="" type="radio"/>	5.3 Inspect last charge date	DATE:2026-04-16 T00:00:00.000000 0
<input checked="" type="radio"/>	5.4 Check all fire extinguishers are securely mounted and in good condition	PASS
<input checked="" type="radio"/>	5.5 Check all fire extinguishers are correctly charged	MONITOR
<input checked="" type="radio"/>	5.6 Inspect last charge date	DATE:2026-04-16 T00:00:00.000000 0

PM ENGINE

<input type="radio"/>	6.1 Perform engine valve set	N/A
<input checked="" type="radio"/>	6.2 Inspect air intake system hoses, pipes, clamps for signs of dirt ingress	PASS
<input checked="" type="radio"/>	6.3 Inspect engine for oil or fuel leaks	PASS

● 6.4 Inspect engine components for missing clamps	PASS
● 6.5 Inspect exhaust system for signs of leaks, loose bolts or missing clamps	PASS
● 6.6 Inspect turbo for security and signs of leaks	PASS
● 6.7 Inspect condition of exhaust lagging	MONITOR
● 6.8 Inspect engine mounts for condition and loose hardware	PASS
● 6.9 Inspect alternator mount condition and adjustment	PASS
● 6.10 Inspect wiring condition and security	PASS
● 6.11 Inspect engine belts	PASS

PM ENGINE COOLING SYSTEM

● 7.1 Check coolant level	PASS
● 7.2 Check condition of radiator cap	PASS
● 7.3 Check condition of radiator core	PASS
● 7.4 Check cooling system for signs of leaks	PASS
● 7.5 Check hose and clamp condition	PASS
● 7.6 Inspect fan condition and operation	PASS
● 7.7 Inspect radiator and fan guard condition	PASS

PM SWING TRANSMISSION

● 8.1 Inspect swing transmission for signs of leaks	PASS
● 8.2 Inspect swing transmission oil level	N/A

PM HYDRAULIC SYSTEM

● 9.1 Check hydraulic oil level	PASS
● 9.2 Inspect hydraulic cylinders for leaks and security	PASS
● 9.3 Inspect hydraulic hoses for leaks, damage, security	PASS

● 9.4 Inspect hydraulic pump condition, leaks, security PASS

● 9.5 Check Pilot Accumulator operation as per OEM Maintenance Procedure - Test Boom Down Functionality with engine off PASS

PM FINAL DRIVES

● 10.1 Inspect LHS final drive mount condition for leaks and security PASS

● 10.2 Inspect LHS oil level and mag plug condition N/A

● 10.3 Inspect RHS final drive mount condition for leaks and security PASS

● 10.4 Inspect RHS oil level and mag plug condition N/A

PM UNDERCARRIAGE

● 11.1 Inspect LHS track tension PASS

● 11.2 Inspect RHS track tension PASS

● 11.3 Inspect tracks for loose/missing bolts PASS

● 11.4 Inspect load and carrier rollers for signs of leaks PASS

● 11.5 Inspect idlers for signs of leaks PASS

● 11.6 Inspect sprocket segments condition PASS

● 11.7 Inspect track frame for cracks, lose or missing hardware PASS

PM FRAME AND BODY

● 12.1 Check panels for damage and security PASS

● 12.2 Check access steps and walkway condition PASS

● 12.3 Inspect boom condition – cracks, missing clamps, damaged pipes, excessive movement, lubrication PASS

● 12.4 Inspect stick condition – cracks, missing clamps, damaged pipes, excessive movement, lubrication PASS

● 12.5 Inspect quick hitch condition and operation PASS

● 12.6 Inspect bucket condition – cracks, wear, damage, mounts N/A

12.7 Inspect GET condition and hardware MONITOR

PM ELECTRICAL SYSTEM

13.1 Check battery condition PASS

13.2 Check battery terminal condition PASS

13.3 Check battery security PASS

13.4 Check battery box drain is clear PASS

13.5 Check wiring condition and security PASS

PM GREASE SYSTEM

14.1 Check all points for acceptable lubrication PASS

14.2 Inspect grease system operation PASS

14.3 Check grease line condition N/A

14.4 Refill grease tank N/A

14.5 Lubricate bucket linkage PASS

14.6 Lubricate blade linkage PASS

14.7 Lubricate boom & stick linkage PASS

14.8 Lubricate swing bearing PASS

PM OPERATOR STATION

15.1 Check all doors for correct opening and closing adjustments and operation N/A

15.2 Inspect condition of door seals N/A

15.3 Check window glass and seal condition N/A

15.4 Check mirror condition and adjustments N/A

15.5 Fill window washer reservoir N/A

15.6 Inspect air con vents condition N/A

15.7 Inspect seat belt and mounting hardware PASS

15.8 Inspect seat condition, operation and mounting PASS

15.9 Replace cabin A/C filter N/A

OIL SAMPLING

16.1 Engine N/A

PM POST SERVICE INSPECTION CHECKS

17.1 All inspections have been completed and rectified as required PASS

17.2 All safety related defects have been repaired or reported PASS

17.3 All defects have been noted and reported PASS

17.4 All fluids are at correct level and drain plugs tight PASS

17.5 All oil samples have visually been inspected and any notable signs of contamination have been reported N/A

17.6 All replaced filters have been cut and inspected and photos added to CAT Inspect and reported to supervisor N/A

17.7 Machine has been recommissioned and ready for operation PASS

17.8 PM service notification marked off in Vision Link N/A

DEFECTS IDENTIFIED

18.1 DEFECTS IDENTIFIED *missing rear insulation wrap for exhaust lagging.
hydraulic oil cooler core need to be replaced.*

OIL USED

19.1 Hydraulic oil 0

19.2 Engine oil 7.25

19.3 Slew oil 0

● 19.4 Gear oil 0

● 19.5 Coolant 0

● Site photo

● Site photo

● Site photo

● Site photo