

Minor Service				
Customer	AUSTRALIAN HAMMER SUPPLIES HIRE	Resource	Reid Lewis	
Contact				
Address	Australian Hammer Supplies Hire Pty Ltd 32 Williamson Road	Job Type Reference	Minor Service	
	Ingleburn NSW 2565	Date	2025-06-23 13:46 - 1	3:51
		Job duration	2:0:00	
		Driving duration	00:00:00	
		Distance travelled	0 km	

Notes 750HR MINOR SERVICE

Customer/Technician

maintained at all times

Resource notes

Minor Service		
	Answer	Notes
General Info/Comments	good	
1.1 Wear Correct PPE at all times	NORMAL	
1.2 All isolation and safe work procedures must be followed	NORMAL	
1.3 Identify task hazards and controls utilising hierarchy or controls model	NORMAL	
1.4 Ensure a competent operator and spotter is utilised to move mobile equipment	NORMAL	
1.5 Ensure all mobile equipment is fundamentally stable	NORMAL	
1.6 Ensure three points of contact is maintained during access and egress	NORMAL	
1.7 Ensure acceptable housekeeping standards are	NORMAL	



2.1 Check all work lights, beacon & reverse alarmfor operation	NORMAL
2.2 Test all dash warning lights, gauges and audible alarms for correct operation	NORMAL
2.3 Check idle timer for correct shut down operation	NORMAL
2.4 Check operation of all three emergency stop buttons	NORMAL
2.5 Check operation of horn	NORMAL
2.6 Check operation of reverse camera	NORMAL
2.7 Check alternator charge voltage - ACTUALV	NORMAL
2.8 Check operation of auto grease systemby manually activating timer	N/A
2.9 Check fire systemcontrol panel for 'Normal'	N/A
5.1 Ensure fire suppression bottle and components are securely mounted and in good condition	N/A
5.2 Ensure fire suppression is correctly charged	N/A
5.3 Inspect last charge date - ACTUAL	N/A
5.4 Check all fire extinguishers are securely mounted and in good condition	NORMAL
5.5 Check all fire extinguishers are correctly charged	NORMAL
5.6 Inspect last charge date - ACTUAL	NORMAL
6.1 Performengine valve set	N/A
6.2 Inspect air intake systemhoses, pipes, clamps for signs of dirt ingress	NORMAL
6.3 Inspect engine for oil or fuel leaks	NORMAL
6.4 Inspect engine components for missing clamps	NORMAL
6.5 Inspect exhaust systemfor signs of leaks, loose bolts or missing clamps	NORMAL
6.6 Inspect turbo for security and signs of leaks	NORMAL
6.7 Inspect condition of exhaust lagging	NORMAL
6.8 Inspect engine mounts for condition and loose hardware	NORMAL
6.9 Inspect alternator mount condition and adjustment	NORMAL
6.10 Inspect wiring condition and security	NORMAL
6.11 Inspect engine belts	NORMAL



lubrication

7.1 Check coolant level	NORMAL
7.2 Check condition of radiator cap	NORMAL
7.3 Check condition of radiator core	NORMAL
7.4 Check cooling systemfor signs of leaks	NORMAL
7.5 Check hose and clamp condition	NORMAL
7.6 Inspect fan condition and operation	NORMAL
7.7 Inspect radiator and fan guard condition	NORMAL
8.1 Inspect swing transmission for signs of leaks	NORMAL
8.2 Inspect swing transmission oil level	N/A
9.1 Check hydraulic oil level	NORMAL
9.2 Inspect hydraulic cylinders for leaks and security	NORMAL
9.3 Inspect hydraulic hoses for leaks, damage, security	NORMAL
9.4 Inspect hydraulic pump condition, leaks, security	NORMAL
9.5 Check Pilot Accumulator operation as per OEM Maintenance Procedure - Test Boom Down Functionality with engine off	NORMAL
10.1 Inspect LHS final drive mount condition for leaks and security	NORMAL
10.2 Inspect LHS oil level and mag plug condition	NORMAL
10.3 Inspect RHS final drive mount condition for leaks and security	NORMAL
10.4 Inspect RHS oil level and mag plug condition	NORMAL
11.1 Inspect LHS track tension	NORMAL
11.2 Inspect RHS track tension	NORMAL
11.3 Inspect tracks for loose/missing bolts	NORMAL
11.4 Inspect load and carrier rollers for signs of leaks	NORMAL
11.5 Inspect idlers for signs of leaks	NORMAL
11.6 Inspect sprocket segments condition	NORMAL
11.7 Inspect track frame for cracks, lose or missing hardware	NORMAL
12.1 Check panels for damage and security	NORMAL
12.2 Check access steps and walkway condition	NORMAL
12.3 Inspect boom condition – cracks, missing clamps, damaged pipes, excessive movement,	NORMAL



•	
12.4 Inspect stick condition – cracks, missing clamps, damaged pipes, excessive movement, lubrication	NORMAL
12.5 Inspect quick hitch condition and operation	NORMAL
12.6 Inspect bucket condition – cracks, wear, damage, mounts	NORMAL
12.7 Inspect GET condition and hardware	NORMAL
13.1 Check battery condition	NORMAL
13.2 Check battery terminal condition	NORMAL
13.3 Check battery security	NORMAL
13.4 Check battery box drain is clear	NORMAL
13.5 Check wiring condition and security	NORMAL
14.1 Check all points for acceptable lubrication	NORMAL
14.2 Inspect grease systemoperation	N/A
14.3 Check grease line condition	N/A
14.4 Refill grease tank	N/A
14.5 Lubricate bucket linkage	NORMAL
14.6 Lubricate blade linkage	NORMAL
14.7 Lubricate boom& stick linkage	NORMAL
14.8 Lubricate swing bearing	NORMAL
15.1 Check all doors for correct opening and closing adjustments and operation	NORMAL
15.2 Inspect condition of door seals	NORMAL
15.3 Check window glass and seal condition	NORMAL
15.4 Check mirror condition and adjustments	NORMAL
15.5 Fill window washer reservoir	NORMAL
15.6 Inspect air con vents condition	NORMAL
15.7 Inspect seat belt and mounting hardware	NORMAL
15.8 Inspect seat condition, operation and mounting	NORMAL
15.9 Replace cabin A/C filter	PASS
16.1 Engine	NORMAL
17.1 All inspections have been completed and rectified as required	NORMAL
17.2 All safety related defects have been repaired or reported	NORMAL
17.3 All defects have been noted and reported	NORMAL



17.4 All fluids are at correct level and drain plugs tight	NORMAL
17.5 All oil samples have visually been inspected and any notable signs of contamination have been reported	NORMAL
17.6 All replaced filters have been cut and inspected and photos added to CAT Inspect and reported to supervisor	NORMAL
17.7 Machine has been recommissioned and ready for operation	NORMAL
17.8 PM service notification marked off in Vision Link	N/A
18.1 DEFECTS IDENTIFIED	NORMAL